

STANDARD DEPARTURE CHART - INSTRUMENT

RJAW / IWOTO

SID and TRANSITION

IWO TWO DEPARTURE

RWY 07/25 : Climb RWY HDG to 1000' or above, then proceed as directed by ATC.

Remarks: IWO TWO DEPARTURE is not illustrated.

CHIDORI TWO DEPARTURE


RWY 07 : Climb RWY HDG to 1000' or above, turn left HDG305° to intercept and proceed via IJT R-335 (336° from OX) to CHIDORI.

RWY 25 : Climb RWY HDG to 1000' or above, turn right HDG005° to intercept and proceed via IJT R-335 (336° from OX) to CHIDORI.

CHIDORI TRANSITION

After CHIDORI, proceed via IJT R-335 (336° from OX) to NORTH CHIDORI.

Cross NORTH CHIDORI at assigned altitude.



STANDARD ARRIVAL CHART - INSTRUMENT

RJAW / IWOTO

STAR

CHIDORI ARRIVAL

From over NORTH CHIDORI, proceed via IJT R-335 to IJT R-335/15DME, then turn right (left) via IJT 15DME counter-clockwise (clockwise) arc to KANGO (SAUNA).

Cross CHIDORI at altitude specified by ATC.

CHIDORI ARRIVAL



RJAW / IWOTO

NDB A


Civil Aviation Bureau, Japan (EFF:31 JAN 2019) 31/1/19

INSTRUMENT APPROACH CHART


RJAW / IWOTO

NDB B

IWO APP 138.3 – 284.6	IWOTO NDB 360 OX $\equiv \equiv \equiv$ <i>24°46'21"N/141°18'27"E</i>	IWO TOWER 126.2 – 228.2	GCA AVAILABLE CALL IWO APP
--------------------------	---	----------------------------	----------------------------------



Remain within 26nm



MISSED APPROACH

At OX NDB, turn right climb via
150° from OX NDB to 3000', then
turn left within 10nm.
Proceed to OX NDB and hold.
Contact IWO APP.

MINIMA		AD elev. 388
CAT	CIRCLING	
	MDA(H)	VIS
A	1060 (672)	1600
B		
C		2400
D		3200

INSTRUMENT APPROACH CHART

RJAW / IWOTO

TACAN Z RWY07





INSTRUMENT APPROACH CHART

RJAW / IWOTO

TACAN Y RWY07

IWO APP 138.3 – 284.6	IWOTO TACAN 996 IJT CH-35X --- 24°47'05"N/141°18'57"E	IWO TOWER 126.2 – 228.2	GCA AVAILABLE CALL IWO APP
--------------------------	--	----------------------------	----------------------------------



MINIMA		THR elev. 361	AD elev. 388	
CAT	CIRCLING			
	MDA(H)	RVR/CMV	MDA(H)	VIS
A	820 (459)	1500	820 (432)	1600
B			840 (452)	
C			860 (472)	
D		2000	940 (552)	3200

INSTRUMENT APPROACH CHART

RJAW / IWOTO

TACAN X RWY07



INSTRUMENT APPROACH CHART

RJAW / IWOTO

TACAN Z RWY25



MISSED APPROACH

1.9DME prior to IJT TACAN, turn left climb via IJT R-150 to R-150 /15DME fix and hold at 3000'.
Contact IWO APP.



MINIMA		THR elev. 388	AD elev. 388	
CAT	CIRCLING		MDA(H)	VIS
	MDA(H)	RVR/CMV		
A	640 (252)	1500	820 (432)	1600
B			840 (452)	
C		1600	860 (472)	2400
D		1800	940 (552)	3200

INSTRUMENT APPROACH CHART

RJAW / IWOTO

TACAN Y RWY25



MISSED APPROACH

1.9DME prior to IJT TACAN, turn
left climb via IJT R-150 to R-150
/15DME fix and hold at 3000'.
Contact IWO APP.



MINIMA		THR elev. 388	AD elev. 388	
CAT			CIRCLING	
	MDA(H)	RVR/ CMV	MDA(H)	VIS
A	640 (252)	1500	820 (432)	1600
B			840 (452)	
C		1600	860 (472)	2400
D		1800	940 (552)	3200

INSTRUMENT APPROACH CHART

RJAW / IWOTO

TACAN X RWY25

