

RJNF / FUKUI

AD CHART

CHANGE : Width of TWY(12.5m→15.0m). Shape of APN.



## STANDARD DEPARTURE CHART -INSTRUMENT

RJNF / FUKUI


RNAV SID

## AWARA ONE RNAV DEPARTURE

Basic RNP1

Note GNSS required.

VAR 8° W(2010)



Note: RWY18: 5.0% climb gradient required up to 1100FT.

AWARA ONE RNAV DEPARTURE

RWY18: Climb on HDG184° at or above 800FT, turn right direct to AWARA.

RWY36: Climb on HDG004° at or above 500FT, turn left direct to AWARA.

Note: RWY18: 5.0% climb gradient required up to 1100FT.

## RWY18

| Rcmd. Path Terminator | Fix ID (Waypoint Name) | Fly Over | Distance (NM) | MAG Track (TRUE Track) | Turn Direction | Altitude (FT) | Speed Limit (KIAS) | Vertical Angle | Navigation Performance |
|-----------------------|------------------------|----------|---------------|------------------------|----------------|---------------|--------------------|----------------|------------------------|
| VA                    | —                      | —        | —             | 184° (175.9°)          | —              | +800          | —                  | —              | Basic RNP1             |
| DF                    | AWARA                  | —        | —             | —                      | R              | —             | —                  | —              | Basic RNP1             |

## RWY36

| Rcmd. Path Terminator | Fix ID (Waypoint Name) | Fly Over | Distance (NM) | MAG Track (TRUE Track) | Turn Direction | Altitude (FT) | Speed Limit (KIAS) | Vertical Angle | Navigation Performance |
|-----------------------|------------------------|----------|---------------|------------------------|----------------|---------------|--------------------|----------------|------------------------|
| VA                    | —                      | —        | —             | 004° (355.9°)          | —              | +500          | —                  | —              | Basic RNP1             |
| DF                    | AWARA                  | —        | —             | —                      | L              | —             | —                  | —              | Basic RNP1             |


## RJNF / FUKUI

RNAV (GNSS) RWY18

CHANGE : VAR, AWARA, Missed Approach

RJNF / FUKUI

Visual REP



※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

CHANGE : Map updated. BRG/DIST from ARP.

| Call sign          | BRG / DIST from ARP | Remarks                                   |
|--------------------|---------------------|---|
| 山 代<br>Yamashiro   | 037°T / 11.1NM      | 山代温泉街<br>Town of the Yamashiro hot-spring |
| 金 津<br>Kanazu      | 007°T / 4.4NM       | JR芦原温泉駅<br>Station                        |
| 勝 山<br>Katsuyama   | 112°T / 14.0NM      | えちぜん鉄道駅<br>Station                        |
| 武 生<br>Takefu      | 190°T / 14.6NM      | JR駅<br>Station                            |
| 亀 島<br>Kamejima    | 263°T / 8.5NM       | 岩礁<br>Reef                                |
| 東 尋 坊<br>Tohjinboh | 320°T / 7.3NM       | タワー<br>Tower                              |
| 福 井 駅<br>Fukuieki  | 180°T / 4.8NM       | JR駅<br>Station                            |