

RJNF / FUKUI

AD CHART

CHANGE : WIND SPEED METER added.



STANDARD DEPARTURE CHART -INSTRUMENT


RJNF / FUKUI

RNAV SID

AWARA ONE DEPARTURE	Basic RNP1
---------------------	------------

Note GNSS required.

VAR 8° W



RWY18: Climb on HDG184° at or above 800FT, turn right direct to AWARA.  
RWY36: Climb on HDG004° at or above 500FT, turn left direct to AWARA.  
Note RWY18: 5.0% climb gradient required up to 1100FT.

RWY18

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	184 (175.9)	-8.5	—	—	+800	—	—	Basic RNP1
002	DF	AWARA	—	—	-8.5	—	R	—	—	—	Basic RNP1


RWY36

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	004 (355.9)	-8.5	—	—	+500	—	—	Basic RNP1
002	DF	AWARA	—	—	-8.5	—	L	—	—	—	Basic RNP1

## INSTRUMENT APPROACH CHART

RJNF / FUKUI

RNP RWY18



RJNF / FUKUI

Visual REP



※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

Call sign	BRG / DIST from ARP	Remarks
山代 Yamashiro	037°T / 11.1NM	山代温泉街 Town of the Yamashiro hot-spring
金津 Kanazu	007°T / 4.4NM	JR芦原温泉駅 Station
勝山 Katsuyama	112°T / 14.0NM	えちぜん鉄道駅 Station
武生 Takefu	190°T / 14.6NM	JR駅 Station
亀島 Kamejima	263°T / 8.5NM	岩礁 Reef
東尋坊 Tojinbo	320°T / 7.3NM	タワー Tower
福井駅 Fukui eki	180°T / 4.8NM	JR駅 Station

CHANGE : VAR.