


AD CHART



STANDARD DEPARTURE CHART - INSTRUMENT

RJFR / KITAKYUSHU

SID

ASARI THREE DEPARTURE

RWY 18 : Climb RWY HDG to 500FT, turn left HDG039°,...


RWY 36 : Climb RWY HDG to 500FT, turn right HDG129°, ...

...to intercept and proceed via SWE R084 to ASARI.

Cross SWE 8.0DME at or above 3000FT.

Note RWY18 : 5.8% climb gradient required up to 500FT due to airspace restrictions only.

RWY36 : 4.0% climb gradient required up to 500FT due to airspace restrictions only.



STANDARD DEPARTURE CHART - INSTRUMENT

RJFR / KITAKYUSHU

TRANSITION

MATSUYAMA TRANSITION

From over ASARI, via SWE R084 to intercept and proceed via UBE R133 to HIMEH,
via UBE R133 to intercept and proceed via MYE R257 to MYE VOR/DME.



CHANGE : Radial FM SWE.


STANDARD DEPARTURE CHART - INSTRUMENT

RJFR / KITAKYUSHU

TRANSITION

MUSASHI TRANSITION

From over ASARI, via SWE R084 to intercept and proceed via UBE R133 to HIMEH, via TFE R346 to TFE VOR/DME.



CHANGE : Radial FM SWE.

STANDARD DEPARTURE CHART - INSTRUMENT

RJFR / KITAKYUSHU

SID

ONGHA TWO DEPARTURE

RWY 18 : Climb RWY HDG to 500FT, turn left,...

RWY 36 : Climb RWY HDG to 500FT, turn right,...

...direct to SWE VOR/DME, proceed via SWE R259 to ONGHA.

Cross SWE VOR/DME at or above 3000FT.

Note RWY18 : 5.8% climb gradient required up to 500FT due to airspace restrictions only.

RWY36 : 4.0% climb gradient required up to 500FT due to airspace restrictions only.



CHANGE : PROC renamed. Radial FM SWE.

STANDARD DEPARTURE CHART-INSTRUMENT

RJFR / KITAKYUSHU

RNAV SID and TRANSITION

KOHEI ONE DEPARTURE DOUGO TRANSITION		RNAV1
Note 1) DME/DME/IRU or GNSS required. ※ The aircraft equipped with only DME/DME/IRU must be able to update its position without delay at the starting point of take-off roll. 2) RADAR service required.	Critical DME	RWY18 : SWE : 2.0NM from DER - 12.0NM to KOHEI UBE : 16.0NM to KOHEI - KOHEI RWY36 : UBE : 12.0NM to KOHEI - KOHEI
	DME GAP	RWY18 : DER - 2.0NM from DER RWY36 : DER - 12.0NM to KOHEI
	Inappropriate Nav aids	See AD1.1.6.10.3. Inappropriate NAVAIDS for RNAV1
<p>VAR 8°W (2017)</p> <p>VOR/DME UBE 110.8 UBE CH-45X 33°56'08"N/131°17'01"E 100FT</p> <p>TACAN KUGA 1177 IWT CH-90X 34°04'48"N/132°08'50"E 2100FT</p> <p>MATSUYAMA (MYE) 334948.4N 1324132.0E</p> <p>DOUGO TRANSITION</p> <p>KOHEI ONE DEPARTURE</p> <p>VOR/DME SUOH 113.85 SWE CH-85Y 33°51'24"N/131°01'46"E 100FT</p> <p>VOR/DME MUSASHI 117.7 TFE CH-124X 33°29'23"N/131°43'44"E 100FT</p> <p>VOR/DME MATSUYAMA 110.65 MYE CH-43Y 33°49'48"N/132°41'32"E 0FT</p> <p>KOHEI 335057.9N 1312540.0E</p> <p>HIMEH 334414.9N 1313651.2E</p> <p>GONBE 333752.3N 1321148.8E</p> <p>Distances and Bearings: 500, 358°, 178°, 17.5, 133°, 29.8, 110°, 27.5, 072°</p>		
<p><u>KOHEI ONE DEPARTURE</u></p> <p>RWY18 : Climb on HDG178° at or above 500FT, turn left direct to KOHEI.</p> <p>RWY36 : Climb on HDG358° at or above 500FT, turn right direct to KOHEI.</p> <p>Note RWY18: 5.8% climb gradient required up to 500FT due to airspace restrictions only. RWY36: 4.0% climb gradient required up to 500FT due to airspace restrictions only.</p>		
<p><u>DOUGO TRANSITION</u></p> <p>From KOHEI, to HIMEH, to GONBE, to MYE.</p>		

STANDARD DEPARTURE CHART-INSTRUMENT

RJFR / KITAKYUSHU

RNAV SID and TRANSITION

KOHEI ONE DEPARTURE

RWY18

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	178 (170.4)	-7.5	—	—	+500	—	—	RNAV1
002	DF	KOHEI	—	—	-7.5	—	L	—	—	—	RNAV1

RWY36

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	VA	—	—	358 (350.4)	-7.5	—	—	+500	—	—	RNAV1
002	DF	KOHEI	—	—	-7.5	—	R	—	—	—	RNAV1

DOUGO TRANSITION

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	KOHEI	—	—	-7.5	—	—	—	—	—	RNAV1
002	TF	HIMEH	—	133 (125.8)	-7.5	11.5	—	—	—	—	RNAV1
003	TF	GONBE	—	110 (102.2)	-7.5	29.8	—	—	—	—	RNAV1
004	TF	MYE	—	072 (064.1)	-7.5	27.5	—	—	—	—	RNAV1

STANDARD DEPARTURE CHART-INSTRUMENT

RJFR / KITAKYUSHU

RNAV TRANSITION

FIATO TRANSITION

RNAV1

Note 1) DME/DME/IRU or GNSS required.
2) RADAR service required.

Critical DME

-

DME GAP


-

Inappropriate Navaids

See AD1.1.6.10.3. Inappropriate NAVAIDs for RNAV1

VAR 8°W (2017)

FIATO TRANSITION



FIATO TRANSITION


From KOHEI, to HIMEH, to ALFET at or above FL160, to MILAN, to FIATO.

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	Vertical Angle	Navigation Specification
001	IF	KOHEI	-	-	-7.5	-	-	-	-	-	RNAV1
002	TF	HIMEH	-	133 (125.8)	-7.5	11.5	-	-	-	-	RNAV1
003	TF	ALFET	-	109 (102.2)	-7.5	19.8	-	+FL160	-	-	RNAV1
004	TF	MILAN	-	072 (065.1)	-7.5	37.3	-	-	-	-	RNAV1
005	TF	FIATO	-	082 (075.2)	-7.5	19.7	-	-	-	-	RNAV1

INSTRUMENT APPROACH CHART

RJFR / KITAKYUSHU

ILS Z or LOC Z RWY 18



RJFR / KITAKYUSHU

TSUIKI APP 119.225 – 315.9	ILS – LOC 109.15 IKQ 331.25 ILS-GP 331.25 ILS-DME CH-28Y	KITAKYUSHU TOWER 118.85 - 126.2	1315 – 2245(UTC) KITAKYUSHU RADIO 118.85 AFIS provided by Fukuoka Airport Office	RADAR AVBL CALL TSUIKI APP
--------------------------------------	---	---	---	---

VAR 8°W (2021)

EQPT REQUIRED
DME
VOR

ASHIYA AD

OZUKI AD

10NM

YAMAGUCHI-UBE AP

D15.5 SWE

MHA 4000

D9.5 SWE

ASARI

D0.7 IKQ

SWE R084

084°

270°

264°

084°

090°

2986

2334

2427

420

197

404

638

257

197

525

919

656

MHA 4500

768

181

VOR/DME
SUOH
113.85 SWE
CH-85Y
33°51'24"N/131°01'46"E

TSUIKI AD

360°

MSA 25NM

4600

4700

5800

6000

SWE

090°


270°

360°

MINIMA		THR elev. 22	AD elev. 21	
CAT			CIRCLING	
	MDA(H)	RVR/ CMV	MDA(H)	VIS
A	500 (479)	1000	500 (479)	1600
B		1200		
C				2400
D			1600	580 (559)

CHANGE: VAR. PROC course.


INSTRUMENT APPROACH CHART



INSTRUMENT APPROACH CHART

RJFR / KITAKYUSHU

VOR A



CHANGE : Call sign(REMOTE→RADIO). AFIS unit added.

RJFR / KITAKYUSHU


VOR B



INSTRUMENT APPROACH CHART

RJFR / KITAKYUSHU

RNAV(RNP) RWY18



CHANGE : Symbol of VOR/DME deleted.

INSTRUMENT APPROACH CHART

RJFR / KITAKYUSHU

RNAV(RNP) RWY18

RNAV(RNP) RWY18Coding Table

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	VPA/ RDH (°/FT)	RNP Value
001	IF	ASARI	-	-	-7.9	-	-	+4000	-	-	-
002	TF	FR850	-	291 (283.6)	-7.9	3.5	-	3000	-	-	1.0
003	TF	FR851	-	291 (283.5)	-7.9	3.6	-	1864	-165	-3.00	0.3
004	RF Center: FRRF1 r=2.06NM	FR852	-	-	-7.9	4.1	L	567	-	-3.00	0.3
005	TF	RW18	Y	178 (170.4)	-7.9	1.6	-	76	-	-3.00/54	0.3
006	FA	-	-	178 (170.4)	-7.9	-	-	+500	-	-	1.0
007	DF	ASARI	-	-	-7.9	-	L	4000	-	-	1.0

Waypoint Coordinates

Waypoint Identifier	Coordinates	RF Arc Center Identifier	Coordinates
ASARI	335338.98N / 1311252.32E	FRRF1	335316.61N / 1310405.62E
FR850	335427.48N / 1310849.77E		
FR851	335517.24N / 1310440.15E		
FR852	335255.76N / 1310139.03E		
RW18	335123.92N / 1310157.83E		

CHANGE : VAR. Course FM FR852 to RW18. MISSED APPROACH course.


INSTRUMENT APPROACH CHART

RJFR / KITAKYUSHU

RNAV(RNP) RWY36


TSUIKI APP 119.225 - 315.9	GNSS and RF required.	KITAKYUSHU TOWER 118.85 - 126.2	1315 - 2245(UTC) KITAKYUSHU RADIO 118.85 AFIS provided by Fukuoka Airport Office	RADAR AVBL CALL TSUIKI APP
-------------------------------	-----------------------	------------------------------------	--	----------------------------------

For uncompensated Baro-VNAV systems, procedure not authorized below -5°C / above 45°C



MISSED APPROACH

From RW36 on track 358°, at or above 500FT turn right, direct to ASARI and hold at 4000FT.
Contact TSUIKI APP.



Missed APCH climb gradient MNM 5.0%

MINIMA	THR elev. 23	AD elev. 21
CAT	RNP 0.30	
	DA(H)	CMV
A	-	-
B	-	-
C	329(306)	1400
D		1600

MINIMA with Missed APCH climb gradient of 2.5% are not established.

RNP AR**Special Authorization Required**

CHANGE : Symbol of VOR/DME deleted.

INSTRUMENT APPROACH CHART

RJFR / KITAKYUSHU

RNAV(RNP) RWY36

RNAV(RNP) RWY36Coding Table

Serial Number	Path Descriptor	Waypoint Identifier	Fly Over	Course °M(°T)	Magnetic Variation	Distance (NM)	Turn Direction	Altitude (FT)	Speed (KIAS)	VPA/ RDH (°/FT)	RNP Value
001	IF	ASARI	-	-	-7.9	-	-	+4000	-	-	-
002	TF	FR690	-	227 (219.1)	-7.9	5.0	-	3000	-	-	1.0
003	TF	FR691	-	227 (219.0)	-7.9	2.9	-	2079	-165	-3.00	0.3
004	RF Center: FRRF2 r=2.06NM	FR692	-	-	-7.9	4.7	R	574	-	-3.00	0.3
005	TF	RW36	Y	358 (350.4)	-7.9	1.6	-	73	-	-3.00/50	0.3
006	FA	-	-	358 (350.4)	-7.9	-	-	+500	-	-	1.0
007	DF	ASARI	-	-	-7.9	-	R	4000	-	-	1.0


Waypoint Coordinates

Waypoint Identifier	Coordinates	RF Arc Center Identifier	Coordinates
ASARI	335338.98N / 1311252.32E	FRRF2	334851.32N / 1310459.78E
FR690	334947.62N / 1310906.28E		
FR691	334733.05N / 1310655.02E		
FR692	334830.46N / 1310233.32E		
RW36	335004.08N / 1310214.17E		

CHANGE : VAR. PROC course. MISSED APPROACH course.

RJFR / KITAKYUSHU

Visual REP




※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

RJFR / KITAKYUSHU

Visual REP

Call sign	BRG / DIST from ARP	Remarks
部崎 Hesaki	355°T / 6.8NM	灯台 Lighthouse
6NM NE	045°T / 6.0NM	海上 Over the sea
6NM E	090°T / 6.0NM	海上 Over the sea
6NM SE	135°T / 6.0NM	海上 Over the sea
苅田 Kanda	202°T / 5.5NM	日産自動車九州工場 Automobile manufacturing plant
石原町 Ishiharamachi	247°T / 9.2NM	JR石原町駅 Station
間島 Majima	252°T / 3.1NM	島 Island
東インター Higashi Inter	263°T / 6.2NM	小倉東I.C.(九州自動車道) Interchange
小倉ステーション Kokura Station	288°T / 8.0NM	JR小倉駅 Station


CHANGE : BRG/DIST from ARP. Remarks(Kanda).



RJFR / KITAKYUSHU

Minimum Vectoring Altitude CHART

VAR 8°W (2022)



CHANGE : VAR.