


## RJTQ / MIYAKEJIMA

## AD CHART



**INTENTIONALLY LEFT BLANK**

STANDARD DEPARTURE CHART -INSTRUMENT

RJTQ / MIYAKEJIMA

SID

SCOTT ONE DEPARTURE

RWY02 : Turn right,...

RWY20 : Climb RWY HDG to 700FT or above, turn left, via MOE R055 to 5.0DME,  
turn left,...

...climb via MOE R024 to SCOTT.



## STANDARD DEPARTURE CHART -INSTRUMENT

RJTG / MIYAKEJIMA

SID

MIYAKE REVERSAL ONE DEPARTURE

RWY02 : Turn right climb via MOE R045 to 2800FT or above, turn right within MOE 15.0DME...

RWY20 : Turn left climb via MOE R150 to 2800FT or above, turn left within MOE 15.0DME...

...proceed to MOE VOR/DME.

Cross MOE VOR/DME at or above 5000FT.



INSTRUMENT APPROACH CHART

RJTQ / MIYAKEJIMA

VOR/DME A





## RJTQ / MIYAKEJIMA

TOKYO CONTROL  
125.9 – 134.15  
318.2 – 227.3

OYAMA VOR/DME  
108.65 MOE  
CH-23Y ---  
34°04'16"N/139°33'41"E

MIYAKE RADIO  
118.05  
AFIS provided  
by Tokyo Airport Office

NO RADAR



**MISSED APPROACH**  
At 3.5DME prior to MOE VOR/DME,  
turn right climb via MOE R-133  
to RASYA and hold at 4,000ft.  
Contact MIYAKE RADIO.

MINIMA		AD elev. 65
CAT	CIRCLING	
	MDA(H)	VIS
A	760 (695)	3200
B		
C	—	—
D		

Circling to East side of RWY only.

CHANGE : Call sign(REMOTE→RADIO). AFIS unit added.

INSTRUMENT APPROACH CHART

RJTQ / MIYAKEJIMA

VOR/DME C



**INTENTIONALLY LEFT BLANK**



## Visual REP

MIYAKE RADIO  
118.05

10NM N



※図中に標高を示す数字がある場合、単位はメートル(m)である。The unit of measurement used to express elevation is meter(m).

Call sign	BRG / DIST from ARP	Remarks
10NM N	360°T / 10.0NM	海上 Over the sea
御蔵島 Mikurajima	170°T / 12.1NM	御山 Mt. Oyama

Note : In the W direction of the airport, A/G COM from Miyake Radio is blinded by Mt. Oyama (2,543ft).

RJTQ / MIYAKEJIMA

LDG CHART



RJTQ / MIYAKEJIMA

Minimum Vectoring Altitude CHART

