

Software Installation

Atmel Studio IDE Installation:

1. Open the following [Link](#).
2. Download will automatically start once clicked on the link above, if not go to [Link](#), scroll down and download the appropriate version of Atmel Studio 6.0 software with respect to the Operating System.




Figure 1: Atmel Studio Web page for Downloading IDE

3. Follow the on-screen instruction to complete the installation.
4. After successfully installing Atmel Studio IDE, launch the application.




Figure 2: Atmel Studio IDE

XCTU installation:

1. Go to this [link](#).
2. Download the XCTU (Windows x84/x64) installation file.
3. Follow the on-screen instructions to complete the installation.
4. After installing XCTU, launch the application to check is everything is working




Figure 3: XCTU