


Power Supply: Use the 3V3 and GND connections from the NUCLEO Arduino Header.
 If you have a breadboard power supply, an ADALM2000, or an Analog Discovery 2, remove them, or any connections to them, from the breadboard.



Note: Connections to the NUCLEO show the STM32 Pin Name as well as the Arduino Pin Name

STM32_PIN_NAME\ARDUINO_PIN_NAME

Sheet: /
 File: 352.sch

Title:

Size: A4
 KiCad E.D.A. kicad (5.1.6)-1

Date:

Rev:
 Id: 1/1