



PRACTICAL – 5



Aim: Working with Projections and WMS Data.


Steps:

Step 1 – Layers > Add Layers > Add Raster Layer. Select the following file and hit add.




Step 2 – Select the layer go in the layer tab and select Save as, enter the following parameters and click OK.






Step 3 – Layer > Add layer > Add raster layer. Select the following layer and hit add.



Step 4 – Project > Properties.



Step 5 – In the project properties open the CRS menu, select the following parameters and hit apply.

