



MIC Paper Solution S22-22415

Python (Government Polytechnic, Nagpur)



Scan to open on Studocu



SUMMER – 2022 EXAMINATION

Subject Name: Microprocessor


Model Answer

Subject Code:

22415

Important Instructions to examiners:

- 1) The answers should be examined by key words and not as word-to-word as given in the model answer scheme.
- 2) The model answer and the answer written by candidate may vary but the examiner may try to assess the understanding level of the candidate.
- 3) The language errors such as grammatical, spelling errors should not be given more Importance (Not applicable for subject English and Communication Skills).
- 4) While assessing figures, examiner may give credit for principal components indicated in the figure. The figures drawn by candidate and model answer may vary. The examiner may give credit for any equivalent figure drawn.
- 5) Credits may be given step wise for numerical problems. In some cases, the assumed constant values may vary and there may be some difference in the candidate's answers and model answer.
- 6) In case of some questions credit may be given by judgement on part of examiner of relevant answer based on candidate's understanding.
- 7) For programming language papers, credit may be given to any other program based on equivalent concept.
- 8) As per the policy decision of Maharashtra State Government, teaching in English/Marathi and Bilingual (English + Marathi) medium is introduced at first year of AICTE diploma Programme from academic year 2021-2022. Hence if the students in first year (first and second semesters) write answers in Marathi or bilingual language (English + Marathi), the Examiner shall consider the same and assess the answer based on matching of concepts with model answer.

Q. No.	Sub Q. N.	Answer	Marking Scheme
1		Attempt any FIVE of the following:	10 M
	a)	Draw the labeled format of 8086 flag register	2 M
	Ans	 <p>8086 flag register format</p> <p>The diagram shows the 16-bit flag register of the 8086 microprocessor. Bits 15 to 12 are labeled 'U' for Undefined. Bits 11 to 0 are labeled with their respective flag names: OF (Overflow flag), DF (Direction flag), IF (Interrupt enable flag), TF (Trap flag), SF (Sign flag), ZF (Zero flag), U (Undefined), AF (Auxiliary carry flag), U (Undefined), PF (Parity flag), U (Undefined), and CF (Carry flag). Arrows point from each flag name to its corresponding bit position. A legend indicates 'U = Undefined'. A list of flag functions is provided on the right: Carry flag (set by carry out of MSB), Parity flag (set if result has even parity), Auxiliary carry flag (for BCD), Zero flag (set if result = 0), Sign flag (MSB of result), Trap flag (for single step), Interrupt enable flag, Direction flag (for string instruction), and Overflow flag.</p>	Correct diagram: 2 marks



	b)	State any two difference between TEST and AND instructions.		2 M	
	Ans			1 mark for each point of comparison	
		TEST	AND		
		This instruction logically ANDs the source with the destination but the result is not stored anywhere.	This instruction logically ANDs the source with the destination and stores the result in destination.		
		e. g .TEST BL ,CL The result is not saved anywhere.	e.g AND BL , CL The result is saved in BL register		
	c)	State the function of editor and assembler.		2 M	
	Ans	Editor: The editor is a program which allows the user to enter and modify as well as store a group of instructions or text under a file name. Assembler: The assembler is used to convert assembly language written by a user or a program into a machine recognizable format.		1 mark for each function	
	d)	Write any two difference between NEAR and FAR procedure.		2 M	
	Ans	SR.NO	NEAR PROCEDURE	FAR PROCEDURE	1 mark for each point of comparison
		1.	A near procedure refers to a procedure which is in the same code segment from that of the call instruction.	A far procedure refers to a procedure which is in the different code segment from that of the call instruction.	
		2.	It is also called intra-segment procedure.	It is also called inter-segment procedure call.	
		3	A near procedure call replaces the old IP with new IP.	A far procedure call replaces the old CS:IP pairs with new CS:IP pairs.	
		4.	The value of old IP is pushed on to the stack. SP=SP-2 ;Save IP on stack(address of procedure)	The value of the old CS:IP pairs are pushed on to the stack SP=SP-2 ;Save CS on stack SP=SP-2 ;Save IP (new offset address of called procedure)	
		5.	Less stack locations are required	More stack locations are required	
		6.	Example :- Call Delay	Example :- Call FAR PTR Delay	
	e)	Write an ALP to add two 8 bit numbers.		2 M	



	Ans	.model small .data a db 06h b db 12h cends .code start: mov ax, @data mov ds, ax mov al, a mov bl, b add al, bl int 3 ends end start	Correct program :2M
	f)	Define immediate addressing mode with suitable example	2 M
	Ans	An instruction in which 8 bit or 16 bit operand (data) is specified in instruction itself then the addressing mode of such instruction is called as immediate addressing mode. Eg. MOV AX, 7120H	Definition :1M Example:1M
	g)	State the use of DAA instruction in BCD addition.	2 M
	Ans	The DAA (Decimal Adjust after Addition) instruction makes the result in Packed BCD from after BCD addition is performed. It works only on AL register.	Explanation :2M
2.		Attempt any <u>THREE</u> of the following:	12 M
	a)	Describe the directives used to define the procedure with suitable example	4 M
	Ans	Directives used for procedure : PROC directive: The PROC directive is used to identify the start of a procedure. The PROC directive follows a name given to the procedure. After that the term FAR and NEAR is used to specify the type of the procedure. ENDP Directive: This directive is used along with the name of the procedure to indicate the end of a procedure to the assembler. The PROC and ENDP directive are used in procedure. Example:	Description: 2 marks Example :2 marks



		<div>Procedure can be defined as</div> <div>Procedure_name PROC</div> <div>----</div> <div>-----</div> <div>Procedure_name</div> <div>ENDP</div> <div>For Example</div> <div>Addition PROC near</div> <div>-----</div> <div>Addition ENDP</div>	
	b)	Write the function of following pins of 8086: (i) BHE (ii) ALE (iii) READY (iv) RESET	4 M
	Ans	(i) BHE: BHE stands for Bus High Enable. It is available at pin 34 and used to indicate the transfer of data using data bus D8-D15. This signal is low during the first clock cycle, thereafter it is active. (ii) ALE: ALE stands for address Latch Enable, as address and data bus are multiplexed, ALE is used to lock either Address or Data. (iii) READY: It is used as acknowledgement from slower I/O device or memory. It is Active high signal, when high; it indicates that the peripheral device is ready to transfer data. (iv) RESET: This pin requires the microprocessor to terminate its present activity immediately	Each pin function 1 mark
	c)	Describe any four assembler directives with suitable example.	4 M
	Ans	1. DB – The DB directive is used to declare a BYTE type variable – A BYTE is made up of 8 bits. Declaration examples: Num1 DB 10h	Each assembler directive 1 mark



		<p>Num2 DB 37H</p> <p>2. DW – The DW directive is used to declare a WORD type variable – A WORD occupies 16 bits or (2 BYTE).</p> <p>Declaration examples:</p> <p>TEMP DW 1234h</p> <p>3. DD – The DD directive is used to declare a double word which is made up of 32 bits =2 Word's or 4 BYTE.</p> <p>Declaration examples:</p> <p>Dword1 DW 12345678h</p> <p>4. EQU - This is used to declare symbols to which some constant value is assigned Each time the assembler finds the given names in the program, it will replace the name with the value or a symbol. The value can be in the range 0 through 65535 and it can be another Equate declared anywhere above or below.</p> <p>.Num EQU 100</p> <p>5. SEGMENT: It is used to indicate the start of a logical segment. It is the name given to the segment. Example: the code segment is used to indicate to the assembler the start of logical segment.</p> <p>6. PROC: (PROCEDURE) It is used to identify the start of a procedure. It follows a name we give the procedure</p> <p>After the procedure the term NEAR and FAR is used to specify the procedure Example: SMART-DIVIDE PROC FAR identifies the start of procedure named SMART-DIVIDE and tells the assembler that the procedure is far.</p>	
	d)	Describe DAS instruction with suitable example.	4 M
	Ans	<p>DAS: Decimal Adjust after Subtraction: - This instruction converts the result of the subtraction operation of 2 packed BCD numbers to a valid BCD number. The subtraction operation has to be only in the AL. If the lower nibble of AL is higher than the value 9, this instruction will subtract 06 from the lower nibble of the AL. If the output of the subtraction operation sets the carry flag or if the upper nibble is higher than value 9, it subtracts 60H from the AL. This instruction modifies the CF, AF, PF, SF, and ZF flags. The OF is not defined after DAS instruction. The instance is following:</p> <p>Example:</p>	<p>Description 2 marks</p> <p>Example 2 marks</p>




		<p>(i) AL = 75 BH = 46 SUB AL, BH ; AL ← 2 F = (AL) – (BH) ; AF = 1 DAS ; AL ← 2 9 (as F > 9, F – 6 = 9)</p>	
3.		Attempt any THREE of the following:	12 M
	a)	Describe memory segmentation in 8086 with suitable diagram.	4 M
	Ans	<div data-bbox="527 564 974 947" data-label="Diagram"> </div> <p>Memory Segmentation: The memory in 8086 based system is organized as segmented memory. 8086 can access 1Mbyte memory which is divided into number of logical segments. Each segment is 64KB in size and addressed by one of the segment register. The 4 segment register in BIU hold the 16-bit starting address of 4 segments. CS holds program instruction code. Stack segment stores interrupt & subroutine address. Data segment stores data for program. Extra segment is used for string data.</p> <ul style="list-style-type: none"> ➤ The number of address lines in 8086 is 20, 8086 BIU will send 20bit address, so as to access one of the 1MB memory locations. ➤ The four segment registers actually contain the upper 16 bits of the starting addresses of the four memory segments of 64 KB each with which the 8086 is working at that instant of time ➤ A segment is a logical unit of memory that may be up to 64 kilobytes. Starting address will always be changing. It will not be fixed. <p>Note that the 8086 does not work the whole 1MB memory at any given time. However, it works only with four 64KB segments within the whole 1MB memory.</p>	Diagram:2M Explanation:2M
	b)	Write an ALP to multiply two 16 bit signed numbers.	4 M



	Ans	<pre>.model small .data A db 2222h B db 1111h Ends .code Mov ax,@data Mov ds,ax Mov AX,a Mov BX,b IMul BX Int 03h Ends End</pre>	Program Code:4M
	c)	Write an ALP to count odd numbers in the array of 10 numbers	4 M
	Ans	<pre>. Model Small .data BLK DB 10h,40h,30h,60h e db ?h o db ?h ends .code mov ax, @data mov ds, ax lea si, BLK mov bl, 00h mov bh, 00h mov cl, 04h up: mov al, [si] ror al, 1 jc go inc bl jmp next go: inc bh next: inc si dec cl jnz up mov e,bl mov o,bh int 3 ends end</pre>	Program Code:4M



	d)	Write a MACRO to perform 32 bit by 16 bit division of unsigned numbers	4 M
	Ans	<pre>.model small Div1 macro no1,no2 mov ax,no1 div no2 endm .data num1 dw 12346666h num2 dw 2222h .code mov ax,@data mov ds,ax div1 num1,num2 ends end</pre>	Program Code:4M
4.		Attempt any <u>THREE</u> of the following:	12 M
	a)	Describe how 20 bit Physical address is generated in 8086 microprocessor with suitable example.	4 M
	Ans	Formation of a physical address:- Segment registers carry 16 bit data, which is also known as base address. BIU attaches 0 as LSB of the base address. So now this address becomes 20-bit address. Any base/pointer or index register carry 16 bit offset. Offset address is added into 20-bit base address which finally forms 20 bit physical address of memory location.	Description:2 M Example:2M



Example

Assume DS= 2632H, SI=4567H

DS : 26320H0 added by BIU(or Hardwired 0)

+ SI : 4567H

2A887H

b) Write an ALP to find largest number in the array.

4 M

Ans

```
.model small
.data
Array db 02h,04h,06h,01h,05h
Ends
.code
Start: Mov ax,@data
      Mov ds,ax
      Mov cl,04h
      Lea si,array
      Mov al,[si]
      Up : inc si
```

Program
Code:4M





		<p>Cmp al,[si]</p> <p>Jnc next</p> <p>Mov al,[si]</p> <p>Next : dec cl</p> <p>Jnz up</p> <p>Int 03h</p> <p>Ends</p> <p>End start</p>	
	c)	Write an ALP to count number of 0' in 8 bit number.	4 M
	Ans	<pre>.MODEL SMALL .DATA NUM DB 08H ZEROS DB 00H .CODE START: MOV AX,@DATA MOV DS,AX MOV CX, 08H ; initialize rotation counter by 8 MOV BX, NUM ;load number in BX UP: ROR BX, 1 ; rotate number by 1 bit right JC DN ; if bit not equal to 1 then go to DN INC ZEROS ; else increment ZEROS by one DN: LOOP UP ;decrement rotation counter by 1 and if not zero then go ;to up MOV CX, ZEROS ;move result in cx register. MOV AH, 4CH INT 21H ENDS</pre>	Program Code:4M



		END ; end of program.	
	d)	Write an ALP to subtract two BCD number using procedure.	4 M
	An s	<pre>.model small .data num1 db 13h num2 db 12h ends .code start: mov ax,@data mov ds,ax call sub1 sub1 proc near mov al,num1 mov bl,num2 sub al,bl das sub1 endp mov ah,4ch int 21h ends end start end</pre>	Program Code:4M
	e)	Describe re-entrant and recursive procedure with suitable diagram.	4 M
	An s	1)Recursive procedure:	Recursive procedure:2M



	<p>A recursive procedure is procedure which calls itself. This results in the procedure call to be generated from within the procedures again and again.</p> <p>The recursive procedures keep on executing until the termination condition is reached.</p> <p>The recursive procedures are very effective to use and to implement but they take a large amount of stack space and the linking of the procedure within the procedure takes more time as well as puts extra load on the processor.</p>  <p>2) Re-entrant procedures:</p> <p>In some situation it may happen that Procedure 1 is called from main program Procedure2 is called from procedure1 And procedure1 is again called from procedure2. In this situation program execution flow re enters in the procedure1. These types of procedures are called re-entrant procedures.</p> <p>A procedure is said to be re-entrant, if it can be interrupted, used and re-entered without losing or writing over anything.</p> 	Re-entrant procedures:2M
5.	Attempt any TWO of the following:	12 M



	a)	(a) Calculate the physical address if: (i) CS 1200H and IP = DE00H (ii) SS = FFO0H and SP = 0123H (iii) DS 1F00H and BX= 1A00H for MOV AX, [BX]	6 M
	Ans	Physical address = segment address x 10H + offset address (i) Physical address = CS X 10H + IP = 1200H X 10H + DE00H = 12000H + DE00H = 1FE00H (ii) Physical address = SS X 10H + SP = FF00H X 10H + 0123H = FF000H + 0123H = FF123H (iii) Physical address = DS X 10H + BX = 1F00H X 10H + 1A00H = 1F000H + 1A00H = 20A00H	Each correct answer 2 mark's
	b)	Describe how an assembly language program is developed and debugging using program developments tools.	6 M
	Ans	Assembly language development tools: EDITOR: It is a program which helps to construct assembly language program with a file extension .asm, in right format so that the assembler will translate it to machine language. It enables one to create, edit, save, copy and make modification in source file. Assembler: Assembler is a program that translates assembly language program to the correct binary code. It also generates the file called as object file with extension .obj. It also displays syntax errors in the program, if any. Linker: It is a programming tool used to convert Object code (.OBJ) into executable (.EXE) program. It combines, if requested, more than one separated assembled modules into one executable module such as two or more assembly programs or an assembly language with C program.	Each development tool 1.5 mark's



		Debugger: Debugger is a program that allows the execution of program in single step mode under the control of the user. The errors in program can be located and corrected using a debugger. Debugger generates .exe file.	
	c)	State the addressing mode of following instructions: (i) MOV AX, 3456H (ii) ADD BX, [2000H] (iii) DAA (iv) MOV AX, [Si] (v) MOV AX, BX (vi) SUB AX, [BX +SI +80H]	6 M
	Ans	(i) MOV AX , 3456H ----- IMMEDIATE ADDRESSING MODE (ii) ADD BX , [2000H] ----- DIRECT ADDRESSING MODE (iii) DAA ----- IMPLIED ADDRESSING MODE (iv) MOV AX , [SI] ----- INDEXED ADDRESSING MODE (v) MOV AX , BX ----- REGISTER ADDRESSING MODE (vi) SUB AX , [BX+SI+80H] ----- BASE RELATIVE INDEX ADDRESSING MODE	Each correct answer 1 mark
6.		Attempt any <u>TWO</u> of the following:	12 M
	a)	Describe how string instructions are used to compare two strings with suitable example.	6 M
	Ans	CMPS /CMPSB/CMPSW: Compare string byte or Words. Syntax: CMPS destination, source CMPSB destination, source CMPSW destination, source Operation: Flags affected < ----- DS:[SI]- ES:[DI] It compares a byte or word in one string with a byte or word in another string. SI holds the offset of source and DI holds offset of destination strings. CX contains counter and DF=0 or 1 to auto increment or auto decrement pointer after comparing one byte/word. e.g.	Explanation of string compare instruction 4 marks And Example 2 marks



		<p>CMPS m8, m8 byte at</p> <p>Compares byte at address DS: SI with address ES: DI and sets the status flags accordingly.</p> <p>CMPS m16, m16 word at</p> <p>Compares word at address DS:(E)SI with address ES:(E)DI and sets the status flags accordingly.</p> <p>CMPSB byte at</p> <p>Compares byte at address DS:(E)SI with address ES:(E)DI and sets the status flags accordingly.</p> <p>CMPSW word at</p> <p>Compares word at address DS:(E)SI with address ES:(E)DI and sets the status flags accordingly.</p>	
	b)	<p>Write an instruction to perform following operations:</p> <p>(i) Multiply BL by 88H (ii) Signed division of AL by BL (iii) Move 4000H to DS register (iv) Rotate content of AX register to left 4 times. (v) Shift the content of BX register to right 3 times. (vi) Load SS with FF00H.</p>	6 M
	Ans	<p>(1) Multiply BL by 88h MOV AL, 88H MUL BL</p> <p>(2) Signed division of AL by BL IDIV BL</p> <p>(3) Move 4000H to DS register MOV DS, 4000H</p> <p>(4) Rotate content of AX register to left 4 times MOV CL, 04</p>	Each correct answer 1 mark



		<p>ROL AX, CL</p> <p>(5) Shift the content of BX register to right 3 times</p> <p>MOV CL,03H</p> <p>SHR BX, CL</p> <p>(6) Load SS with FF00H</p> <p>MOV AX, FF00H</p> <p>MOV SS, AX</p>	
	c)	Write an ALP to concatenate two strings.	6 M
	Ans	<pre>DATA SEGMENT STR1 DB "hello\$" STR2 DB "world\$" DATA ENDS CODE SEGMENT START: ASSUME CS: CODE, DS:DATA MOV AX,@ DATA MOV DS, AX MOV SI, OFFSET STR1 NEXT: MOV AL, [SI] CMP AL,'\$' JE EXIT INC SI JMP NEXT EXIT: MOV DI, OFFSET STR2 UP: MOV AL, [DI] CMP AL, "\$" JE EXIT1</pre>	Correct program 6 marks



	<pre>MOV [SI], AL INC SI INC DI JMP UP EXIT1: MOV AL, '\$' MOV [SI], AL MOV AH, 4CH INT 21H CODE ENDS END START</pre>	
--	---	--