

Automated Home-cage System Construction Manual

Contents

1. Build an Enclosure.....	1
2. Components on the Enclosure Side Boards.....	2
3. Lickport Station	3
4. Weighting Stage and Home-cage.....	4
5. Headport	5
6. Pneumatics.....	9
7. Circuit and Assembly.....	10
8. Prepare Computer	12
9. Testing Procedure	12

1. Build an Enclosure

- Get six **9"construction rails** (XE25L09) and two **20" rails** (XE25L20). Lay out three of the 9" rails in a "U" shape, with the two side rails laying on top of the bottom rail (Fig1.1). Join the rails using two **setscrews** (SS25S075) and **drop-in T-nuts** (XE25T1). Repeat above steps to make another "U" shape.
- Connect two 'U' shape together with 20" construction rails at top corners. Join the rails with two setscrews and drop-in T-nuts in one side and fasten with two **right angle brackets** (AB90H), **drop-in T nuts**, and 1/4-20 screws in the other side (Fig.1.2).
- Cut one 9"x22" **thick acrylic board** (8505K758) and fix it at the bottom of the enclosure using ¼-20 screws and drop-in T-nuts. Cut two 9"x10", two 10"x22" and one 9"x22" **thin acrylic boards** (8505K745). Attach one 9"x10" and one 10"x22" board on the back and right side of the enclosure, respectively, with ¼-20 screws and drop-in T-nuts (Fig1.3).
- Cut ten 9" and four 22" strips of **magnetic tape**. Pair together and place adhesive of one of the two paired strips on left side and front rails. Remove adhesive on other strip of magnetic tape pairs. Carefully align 9"x10" and 10"x22" acrylic sheets with their respective sides. Press firmly to secure adhesive to edges of acrylic sheet.
- Cut a rectangular hole (7"x7") on the 9"x22" board and cover it with **metal mesh**. Place the board on the top to cover the enclosure (Fig1.4).



Fig. 1.1



Fig.1.2



Fig.1.3



Fig.1.4

2. Components on the Enclosure Side Boards

- Get an **analog pressure regulator** (FESTO, 557773). Screw one **L-shape push-in-fit** (5225K564) in the inlet hole, and another **L-shape push-in-fit** (5779K425) in the outlet hole. Screw a **silencer** (9836K21) at the exhaust hole (hole no. 3).
- Get a **manual pressure regulator** (LR-M5-D-7-MICRO) and fit with two **push-in fitting** (QSM-M5-6).
- Fix the above two regulators on the back board of the enclosure. (Fig.2.1).
- Get a custom **breakout PCB board** (BCM-NL-HCT001). Solder three **solid state relays** (CC1139-ND), one **HX711 amplifier** (SparkFun, SEN-13879), one **MCP4725 DAC** (Adafruit, 935), one **LED driver** (SparkFun, SS25S075), one **6-pin 2x3 box header connector** (JP1), one **16-pin 2x8 box header connector** (JP2), one 9-pin (JP4), one 6-pin (JP6) and one 16-pin 2x8 straight header connectors (JP5), on the PCB board (Fig.2.2).




Fig.2.1




Fig. 2.2

- Fix three **Arduino boards** (Mouse, A000062), one custom **lickometer PCB**, one **9V battery case**, one **3/2-way solenoid valve** (FESTO, 196847) and custom breakout PCB on the enclosure right board (Fig.2.3). Assemble a **SD card shield** (<https://www.adafruit.com/product/1141>), connect DIO5 to CD via a jump wire, and insert the **SD card shield** into Arduino_Master board.




Fig. 2.3

3. Lickport Station

- Cut two 18", two 9", and two 2" pieces of 1/32" **plastic tubing** (Tygon E-3603).
- Remove plungers from two **30 mL syringes**. Tape syringes together at top with regular tape. Attach **female luers** (45508-02) to syringes. Attach 18" tubing to luers.
- Attach 9" tubing to top port of two Lee company **solenoid valves** (LHDA1233215H), and 18" tubing from 30 mL syringes to middle ports. Tie each of 2" pieces in knot and slide one end over the bottom ports (Fig.3.1)
- Cut two 2" pieces of **18G stainless steel tubing** with Dremel tool. Smooth at least one end for licking.
- Slide steel tubing into the two holes of the custom **lickport holder**. These holes may need to be reamed out with a #51 drill bit. Place tubes securely with ~ 1/2" sticking out of front end. Glue if necessary.
- Get two 10" wires (different color) and solder one end to steel tubing. Slide a piece of **heat shrink** over tubing and soldered wire. Heat with heat gun to shrink material and create tight fit. Crimp the other end of the wires to a female pin connector (Fig.3.2)
- Slide free ends of 9" plastic tubing over steel tubing on the heat shrink side.



Fig. 3.1




Fig.3.2

- Get a 3D-printed **switch holder** and two **mini toggle switches**, one for left solenoid and one for right solenoid. Fix the switches to the holder (Fig.3.3).
- Get five cables of 24". Solder these 5 cables to the switches' pin1, pin2 and pin3 accordingly as shown in the picture (Fig.3.4, Fig.3.5).
- Label "Flush" on the front panel of the switch holder to indicate the direction in which the switch is toggled to Pin1.



Fig. 3.3




Fig. 3.4




Fig. 3.5

4. Weighting Stage and Home-cage

- Get 3D-printed parts **WeightingStage_bottom** and **WeightingStage_top**, a **micro load cell** (Phidgets, 100g), a piece of **aluminum sheet** (2.5"x1.25"x0.016") and a **flat ribbon cable** of 20 cm with one end having 6-pin (2x3) female connector (Fig.4.1).
- Fix the load cell on the WeightingStage_bottom using two screws (M2.5x12mm) and nuts. Make sure the arrow on the load cell is downward.
- Strip two ends of a wire. Tape one end of the striped wire on the aluminum sheet by aluminum tape. Route the other end of the wire out of the hole of WeightingStage_top and then out of the hole of WeightingStage_bottom. Glue the aluminum sheet on top of WeightingStage_top and let the side with the wire attached facing down.
- Secure WeightingStage_top on the load cell using another two screws (M2.5x12 mm) and nuts (Fig.4.2).
- According to the connector pinout in Table1, solder the four wires from load cell and one wire from the aluminum sheet to the open end of the ribbon cable (Fig. 4.3).




Fig. 4.1




Fig. 4.2




Fig. 4.3

Table 1. 6Pin (2x3) female connector Pinout

Connector Pin#	Weighting Stage Wire
Pin 4	AL Sheet
Pin 2	RED
Pin 5	BLACK
Pin 3	WHITE
Pin 1	GREEN

- Align the custom 3D-printed **headport** and the **weighting stage** assembled above against one side of the **home-cage**. According to the positions of the headport, drill two holes (7 mm) and one opening (30mm x 30mm). The headport should be attached to the home-cage such that the lower edge of the home-cage opening is trimmed with the weighting stage and the lower edge of the headport opening is a bit higher than the weighting stage (Fig.4.4).
- Drill a small opening (~15mm x 10mm) on the lower side of the home-cage to allow the ribbon cable connector (2x3 female connector) of the weighting stage go through.
- Align the weighting stage on the floor of the home-cage, centered around the opening. Mark the mounting locations and drill four threaded holes (4-40) on the floor. Fix the weighting stage to the threaded holes using size 4-40 screws (Fig.4.5).




Fig.4.4



Fig.4.5

5. Headport

5.1. Apply aluminum tape on the headport (Fig. 5.1):

- Apply aluminum tape on the floor of the headport opening and route it to the side of the headport by another piece of aluminum tape.
- Get a wire, strip two ends. Attach one end of the wire to the aluminum tape on the side of the headport and the other end of the wire will be soldered to the Headport ribbon cable.




Fig. 5.1



Fig.5.2

5.2. Set up switches (Fig.5.4):

- Get two snap action switches (D429-R1ML-G2) and four screws (M3x25mm) and nuts (Fig.5.3).
- Bend the first 3 mm of the switch lever outward to form a 90-degree angle.
- Fix the two switches on each side of the switch holder in the headport with the screws and nuts. Adjust the position to make sure the switches can be triggered only when the **headbar** (Fig.5.2) reaches the end of the headbar track of the headport.
- Connect pin1 of the two switches by soldering a jump wire. Solder a wire to pin4 of each switch and a wire to pin1 of one switch. These wires are with the other end free and to be soldered to the Headport ribbon cable.




Fig.5.3




Fig.5.4

5.3. Set up motors (Fig.5.5, Fig.5.6):

- Get one 50mm and one 30mm stroke **motor (Actuonix, L12)**.
- Get one 3D-printed **motor holder** and thread the holes with 6-32 and 8-32 tap. Fix the 50mm motor at the tip of the 30mm motor in an orthogonal way using the 3D-printed holder with 6-32 x 1/4" screws and 8-32 x 1/2" screw.
- Fix the lickport holder at the tip of 50mm motor using one screw (M4x25mm) and three nuts.
- Thread the two holes located at the lower right side of the headport floor using 6-32 tap. Fix the motors on the headport floor using a bracket set which is came with the motor and 6-32 x 3/8" screws. Be sure to put a thin washer under the bracket to adjust the gap between the motor and the headport floor.
- From each motor, take red, black and blue wires and put them together into a 1x3 pin connector housing to be connected to the Headport ribbon cable.



Fig.5.5




Fig.5.6

5.4. Set up head-fixation pistons (Fig.5.7):

- Get two **1/4" OD Air Cylinder Pistons** (McMaster, 6604K11) (with hex nuts). Grind the hex nuts outer shape to match the headport with Dremel.
- Insert two shaped hex nuts in the headport, screw the pistons in the piston holes of the headport and fix them with two **Panel Nuts** (McMaster, 5601396540).

- Screw two **Push-in-Fitting connectors** (McMaster, 5779K246) in the air inlet holes of the pistons.



Fig.5.7

5.5. Set up pole mechanism (Fig.5.8, Fig.5.9):

- Get one **Air Cylinder Pistons** (McMaster, 6498K999). Insert the piston into the pole holder of the headport and screw one **hex nut** (10-32) on the rod of the piston until flush.
- Get one 3D printed **pole** and one 30mm stroke **motor** (Actuonix, L12-30). Insert the pole into the hole at the tip of motor. Take red, black, blue and purple wires from the motor and put them together into a 1x4 pin connector housing to be connected to the Headport ribbon cable.
- Fix the motor at the end of the piston with 3D printed **bracket**. Screw two hex nuts (3/8"-24) at the end until flush.
- Screw one **Push-in-Fitting connectors** (McMaster, 5779K246) in the air inlet holes of the pistons.



Fig.5.8




Fig.5.9

5.6. Set up Piezo Buzzer (Fig.5.10)

- Get a **Piezo Buzzer** (490-CPE-160) and a cable with one end free and one end pre-crimped. Solder the free end of the cable to the Buzzer and have the other end ready to be connected to the headport ribbon cable. Fix the buzzer on the Headport floor.



Fig.5.10




Fig.5.11

5.7. Built the headport ribbon cable

- Get a **flat Ribbon cable** of 20cm with one end having 16Pin (2x8) female connector and the other end free.
- According to the connector pinout in Table2, solder and connect all the electric components located at the headport to the headport ribbon cable (Fig.5.11).

Table2. 16Pin (2x8) female connector Pinout:

Connector Pin#	Headport Electric Components Wires
Pin 1,3,5,16	NC
Pin 9	Piezo Buzzer + (Red)
Pin 11	Switch L (pin4)
Pin 13	Switch R (pin 4)
Pin 15	Motor LR/FB/Pole GND (Black), Switch Com(pin1), Piezo Buzzer- (Black)
Pin 2	Motor LR/FB/Pole Power (+12v, Red)
Pin 4	Motor LR Voltage Input (Blue)
Pin 6	Motor FB Voltage Input (Blue)
Pin 7	Motor Pole Position Feedback (Purple)
Pin 8	Motor Pole Voltage Input (Blue)
Pin 10	Lickport Right
Pin 12	Lickport Left
Pin 14	Headport AL Tape

6. Pneumatics

- Attach a **push-in-fit** (QSM-M7-6-I) in the exhaust hole of the **3/2-way solenoid valve** (hole no. 3). Connect it to a **flow control valve** (GRLA-1/8-QS-6-RS-D) using **6-mm tubing** (Freelin-Wade, 1E-158-08)
- Get another flow control valve, attach a **female push-in-fit** (QSF-1/8-6-B) on the threaded port.
- Connect all the pneumatic parts using 6-mm tubing according to Fig.6.1.
- Attach a **power/control cable** (SIM-M12-5GD-2,5-PU) to the analog pressure regulator




Fig. 6.1

7. Circuit and Assembly




Fig.7.1

- Connect the electric circuit according to the above diagram Fig.7.1. The components in the circuit can be located at Fig.2.1, Fig.2.2, Fig.2.3 and Fig.3.4 accordingly. Fig.7.2 shows the completed circuit connection.




Fig. 7.2

- Use a 4-way Barrel Jack Splitter (Mouser, 485-1352) to connect together 12v power input ports on the three Arduino boards and BCM-NL-HCT001 board, and then connect the Splitter to a 12v AC/DC wall mount Adapter.
- Mount the Lee solenoids (Fig.7.3), reward switches (Fig.7.4) and Arduino switch (Fig.7.5) on the enclosure frame (Fig.7.6).



Fig.7.3



Fig.7.4



Fig.7.5



Fig.7.6


- Table3 shows input/output of wires/pipes for the **Automated Home-cage System** after assembly.

Table3. Home-cage I/O

	Item Name	Function
Input	12v AC/DC wall mount Adapter	Provide 12v power for Arduinos, motors and Lee solenoids
	24v AC/DC wall mount Adapter	Provide 24v power for 3/2-way solenoid valve and analog pressure regulator
	USB 2.0 to Micro B Cable	Connect Arduino_Master to PC
	Plastic tube	Provide Air supply (4-bar) to Home-cage
Output	BNC Cable	Send voltages (0-5 V) to control Laser

8. Prepare Computer

The following software should be installed to the computer for testing and operating the Automated Home-cage System:

- Download the latest version of **MATLAB** from <https://www.mathworks.com>. After installed it, do the following steps to adjust **Java Heap Memory** to be half of the full Java Heap Size:
 - Start MATLAB.
 - On the **Home** tab, in the **Environment** section, click  **Preferences**. Select **MATLAB > General > Java Heap Memory**.
 - Select a Java heap size value using the slider or spin box.
 - Click **OK**.
 - Restart MATLAB.
- Download the Serial/TCP Terminal (**realterm.exe**) from <https://sourceforge.net/projects/realterm/files/Realterm/>
- Download the latest version of the **Arduino IDE** from <https://www.arduino.cc>. After installed it, with the Arduino plugged into a USB port, start up the IDE and make sure that the correct board name/version and COM port appears under the **Tools** menu.
 - The COM port can be seen in the Windows Device Manager.
 - A support package for Arduino DUE needs to be downloaded via the IDE:
 - Click the menu item **Tools → Board → Boards Manager**.
 - Search 'due' and find Arduino Due package.
 - Click on the **Install** button that appears.
 - Copy all the files in the folder "\\Arduino programs\\Tactile delayed response task\\Library\\" to the PC folder: \\Program Files (x86)\\Arduino\\libraries\\.
 - To upload an Arduino program to Arduino board via the IDE, do the following steps:
 - Connect a USB cable from PC to the Native USB of the Arduino board.
 - Click the menu item **File → Open**, select the program.
 - Click the menu item **Tools → Board**, select the correct Arduino port
 - Click the menu item **Tools → Port**, select the correct COM port.
 - Click the button **Upload**.

9. Testing Procedure

9.1. SD Card

- Insert a battery (CR1220) to SD card shield.
- Copy all the files in the folder "\\Test\\final config files\\" to a SD card.
- Insert the SD card to SD card shield.

9.2. On-board Date/Time Correction

- Upload "\\Test\\correctTime\\correctTime.ino" to Arduino_Master board.
- After upload is done, run **Realterm.exe** on PC to receive Date/Time info from Arduino_Master board. The current Date/Time should be read on the Realterm display window.
- Do not reset Arduino when this step is done.

9.3. Weight Calibration

- Do not reset Arduino from last step.
- Upload "\\Test\\Weight_Calibration\\Weight_Calibration.ino" to Arduino_Master board and run Realterm.exe on PC to receive weight info.

- After readings start, place an object with known weight on the weighting stage. The reading on the Realterm display window should be roughly matched to the weight. Adjust the calibration_factor if the reading is not matched.
- Set the correct calibration_factor in the program “\Arduino programs\XXX task\Arduino_Master\Arduino_Master.ino”.

9.4. Upload Arduino program

In the folder “\Arduino programs\Tactile delayed response task\”:

- Upload “\Arduino_Wave\Arduino_Wave.ino” to the Arduino_Wave board.
- Upload “\Arduino_Task\Arduino_Task.ino” to the Arduino_Task board.
- Upload “\Arduino_Master\Arduino_Master.ino” to the Arduino_Master board.

9.5. Air/Power supply

- Supply the **plastic tube** of the Automated Home-cage System with the compressed air **4 bars**.
- Adjust the manual pressure regulator (Fig.2.1) to **2 bars** and check if there is air leaking.
- Power up the Automated Home-cage System with **12V and 24V adapters**.
- Connect the USB cable from the Native USB Port of the Arduino_Master board to PC.

9.6. Test motors and adjust motor position

- Run “\Matlab GUI\homecage_gui.m” program in MATLAB and the HomeCage GUI shows up as Fig.9.1.
- In HomeCage GUI, choose a cage and open the corresponding COM.
- In Control Panel of HomeCage GUI, choose the above cage, input a value (0-255) and click “**Move & Set**” to see if the corresponding motor moves by the expected distance.
- Move the **LR motor** to the initial position (70 by default), loose the bracket which holds the LR motor, adjust the location of the **LR motor** so that the lickport is roughly at the center of the head port.
- Move the **FB motor** to the final position (30 by default), loose the bracket which holds the FB motor, adjust the location of the **FB motor** so that the tip of the lickport is about 14 mm from the wall of the headport. And then move the FB motor to the position 130, the tip of the lickport should just touch the wall.

9.7. Test Tare function

- Make sure nothing is on the weighting stage and click **Tare** button in HomeCage GUI.
- Click **Read** button, the text field of **Weight** should show a value close to zero.
- Put an object with known weight **W** (g) on the weighting stage and click **Read** button again, the text field of **Weight** should show a value close to **W** (g).

9.8. Test the reward solenoid valves

- Fill the **water reservoir** with water.
- Toggle the reward switch to the “Flush” side to turn on the solenoid valve. The water should flow out of the water reservoir, fill up the whole tubing and then flow out of the lickport.
- Toggle the reward switch to the other side. When turn on the Arduino switch, A drop of water should come out of both lickport tubes.
- Click **Set&Reward** button in Homecage GUI, and a drop of water should also come out of both lickport tubes.



Fig.9.1

9.9. Test the lickometer board (Fig.9.2)

- The two Trimmer Resistors (R10/R21) on the lickometer board should be turned to the maximum value.
- The two capacitors on the lickometer board should be 0.47uf.
- Measure the voltage between the left and right pins in J3/J5 of the lickometer board, the resting voltage is around 0.3v, and the voltage goes up to around 3.8v when you connect the left/right lickport to the aluminum tape on the headport by your hand.
- Connect both J3 and J5 to an oscilloscope (left pin to probe and right pin to ground), touch the lickport by your hand, and check if there is any crosstalk between the two lickport tubes. Adjust R10/R21 and change the capacitors if necessary.




Fig.9.2

9.10. Test the trial sequence

9.10.1. Trial sequence

- With the SD card having the final config files, turn on the Arduino switch and trigger the two switches in the headport by the headbar. The trial runs with the following sequence:
 - 1) Pistons for head-fixation comes down.
 - 2) Motor for pole moves either forward or backward depending on the trial type.
 - 3) Masking LED turns on and flashes.
 - 4) Piston for pole comes down and stays down for about 1.3s.
 - 5) Piston for pole comes up.
 - 6) Piezo Buzzer makes a go cue sound.
 - 7) Masking LED off.
- Trials repeat the above sequence (1-7) until the head fixation is timeout (~60s), and then the Pistons for head-fixation comes up. Each trial takes about 6s.

9.10.2. Checking List

During a trial, check the functionality of the following items:

- **Pistons for head-fixation:** coming down and retracting smoothly, fixation (staying down) for ~60s.
- **Piston for pole:** coming down and retracting smoothly. Adjust the flow control valves if necessary.
- **Motor for pole:** moving forward and backward smoothly.
- **Masking LED:** flashing during the whole trial (~5 sec).
- **Lickports:** the left and right lickports can be detected separately and correctly. Depending on the trial type, a drop of water should come out of the left/right lickport if connecting the corresponding lickport to the aluminum tape on headport/weighting stage by your hands right after the go cue sound is heard in each trial.
- **Weighting stage:** during head-fixation, press or lift the weighting stage lightly, the pistons for head-fixation should be released.