




- Notes:
- 1. Adjust dimensions of trolley according to size of your sorting containers
  - 2. Grind all surfaces to be welded about 25mm from weld
  - 3. Tack weld the whole frame
  - 4. Check that everything is square and all measurements are accurate
  - 5. Fully weld all seams

8	2	sorting containers	n/a	n/a	n/a	R-PP
7	4	casters	n/a	n/a	n/a	mix
6	2	underlayment 15mm	755	90	90	plywood
5	8	flat bar 20 x 3	75	45	45	mild steel
4	2	square tube 30 x 30 x 2	490	90	90	mild steel
3	4	square tube 30 x 30 x 2	760	90	90	mild steel
2	4	square tube 30 x 30 x 2	550	45	45	mild steel
1	4	square tube 30 x 30 x 2	900	45	45	mild steel
ITEM NO.	QTY.	DESCRIPTION	LENGTH	ANGLE1	ANGLE2	MATERIAL

	Workspace <b>Shredder</b>		Description <b>Large sorting trolley</b>				
	Projection method <b>First angle</b>		Release date 07/01/20	Drawing no. SHRWS-V1-1100.00		Rev. A	
	General tolerances <b>ISO-2768-m</b>		Doc type <b>Assembly</b>	Units unless specified <b>mm</b>	Sheet size <b>A3</b>	Scale <b>1:10</b>	Sheet <b>1/2</b>



	Workspace <b>Shredder</b>		Description <b>Large sorting trolley</b>				
	Projection method <b>First angle</b>		Release date 07/01/20	Drawing no. SHRWS-V1-1100.01		Rev. A	
	General tolerances <b>ISO-2768-m</b>	Doc type <b>Part</b>	Units unless specified <b>mm</b>	Sheet size <b>A3</b>	Scale <b>1:10</b>	Sheet <b>2/2</b>	