



NOTES: Make two. Use countersunk screws in vaccuum bag to form countersinks.

Make mold 0.005" larger than solar panel.
Max thermal expansion is below 0.002"

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES: 0.X ± 0.1 0.XX ± 0.01 0.XXX ± 0.005				FINISH:			DEBURR AND BREAK SHARP EDGES	DO NOT SCALE DRAWING		REVISION 2		
NAME		SIGNATURE		DATE				TITLE: Mounting Tray				
DRAWN		Bradley Anderson										
CHK'D												
APPV'D												
MFG												
Q.A						MATERIAL:		DWG NO.			A3	
						Carbon Fiber						
						WEIGHT:		SCALE:2:1			SHEET 1 OF 1	