

# Functional description

## OVERVIEW

---

The P1 is Particle's tiny Wi-Fi module that contains both the Broadcom Wi-Fi chip and a reprogrammable STM32F205RGY6 32-bit ARM Cortex-M3 microcontroller. The P1 comes preloaded with Particle firmware libraries, just like our dev kits, and it's designed to simplify your transition from prototype to production. The P1 is the PØ's big brother; it's a bit bigger and a tad more expensive, but it includes some extra flash and an antenna and U.FL connector on board.


## FEATURES

---

- Particle P1 Wi-Fi module
  - Broadcom BCM43362 Wi-Fi chip
  - 802.11b/g/n Wi-Fi
  - STM32F205RGY6 120Mhz ARM Cortex M3
  - 1MB flash, 128KB RAM
  - 1MB external SPI flash (MX25L8006E)
  - Integrated PCB antenna
  - Integrated U.FL connector for external antenna
  - Integrated RF switch
- 25 Mixed-signal GPIO and advanced peripherals
- Open source design
- Real-time operating system (FreeRTOS)
- Soft AP setup
- FCC, CE and IC certified

# Interfaces

## BLOCK DIAGRAM



## POWER


Power to the P1 is supplied via 3 different inputs: VBAT\_WL (pin 2 & 3), VDDIO\_3V3\_WL (pin 5), VDD\_3V3 (pin 26 & 27). Optionally +3.3V may be supplied to VBAT\_MICRO (pin 38) for data retention in low power sleep modes. Each of these inputs also requires a 0.1uF and 10uF ceramic decoupling capacitor, located as close as possible to the pin (see Fig 1). The voltage should be regulated between 3.0VDC and 3.6VDC. (Please refer to [Absolute Maximum Ratings](#) for more info).

Typical average current consumption is 80mA with 5V @ input of the recommended SMPS power supply with Wi-Fi on. Deep sleep quiescent current is typically 80uA (Please refer to [Recommended Operating Conditions](#) for more info). When powering the P1 make sure the power supply can handle 600mA continuous. If a lesser power supply is provided, peak currents drawn from the P1 when transmitting and receiving will result in voltage sag at the input which may cause a system brown out or intermittent operation.

**Warning:** When powering the P1 from long wires, care should be taken to protect against damaging voltage transients if using the same regulator as is used on the Photon. **From the Richtek datasheet:**

*When a ceramic capacitor is used at the input and the power is supplied by a wall adapter through long wires, a load step at the output can induce ringing at the input, VIN. At best, this ringing can couple to the output and be mistaken as loop instability. At worst, a sudden inrush of current through the long wires can potentially cause a voltage spike at VIN large enough to damage the part.*

To avoid these voltage spikes, keep input wiring as short as possible. If long wires are unavoidable, it is advisable to add a 5.1V zener diode or similar transient suppression device from VIN to GND. Another technique is adding more capacitance to the input using an electrolytic capacitor. Please refer to [AN-88 by Linear](#) for a good discussion on this topic.



**Fig. 1** Recommended power connections with decoupling capacitors.

## RF

The RF section of the P1 includes an on-board PCB trace antenna and a U.FL connector which allows the user to connect an external antenna. These two antenna outputs are selectable via a user API, made possible by an integrated RF switch.

The default selected antenna will be the PCB antenna.

The area surrounding the PCB antenna on the carrier PCB should be free of ground planes and signal traces for maximum Wi-Fi performance.

## FCC APPROVED ANTENNAS

Antenna Type	Manufacturer	MFG. Part #	Gain
Dipole antenna	LumenRadio	104-1001	2.15dBi
PCB Antenna	Included	-	-

## PERIPHERALS AND GPIO

---

The P1 module has ton of capability in a super small footprint, with analog, digital and communication interfaces.

**Note:** P1 pin names will be preserved as they are named in the USI datasheet, however for the scope of this datasheet we will also refer to them as their Photon and code equivalents, i.e. D7 instead of MICRO\_JTAG\_TMS and A2 instead of MICRO\_GPIO\_13. This will help to simplify descriptions, while providing a quick reference for code that can be written for the P1 such as `int value = analogRead(A2);`

Peripheral Type	Qty	Input(I) / Output(O)	FT <sup>[1]</sup> / 3V3 <sup>[2]</sup>
Digital	24	I/O	FT/3V3
Analog (ADC)	13	I	3V3
Analog (DAC)	2	O	3V3
SPI	2	I/O	3V3
I2S	1	I/O	3V3
I2C	1	I/O	FT
CAN	1	I/O	3V3 <sup>[4]</sup>
USB	1	I/O	3V3
PWM	12 <sup>[3]</sup>	O	3V3

### Notes:

<sup>[1]</sup> FT = 5.0V tolerant pins. All pins except A3 and DAC are 5V tolerant (when not in analog mode). If used as a 5V input the pull-up/pull-down resistor must be disabled.

<sup>[2]</sup> 3V3 = 3.3V max pins.

<sup>[3]</sup> PWM is available on D0, D1, D2, D3, A4, A5, WKP, RX, TX, PIS0, PIS1, PIS6 with a caveat: PWM timer peripheral is duplicated on two pins (A5/D2) and (A4/D3) for 10 total independent PWM outputs. For example: PWM may be used on A5 while D2 is used as a GPIO, or D2 as a PWM while A5 is used as an analog input. However A5 and D2 cannot be used as independently controlled PWM outputs at the same time. PIS6 requires System Feature Wi-Fi Powersave Clock to be disabled. See System Features in Firmware Reference.

<sup>[4]</sup> Technically these pins are 5.0V tolerant, but since you wouldn't operate them with a 5.0V transceiver it's proper to classify them as 3.3V.

## RGB LED, SETUP AND RESET BUTTON

---


When using the P1 module, it is very important to remember that your device must have an RGB LED to show the user the connectivity status. Also required is a SETUP and RESET button to enter various [Device Modes](#). By default the RGB LED outputs are configured for a Common Anode type of LED. These components should be wired according to the [P1 Reference Design - User I/O](#). RGB pins may be accessed in code as: RGBR, RGBG and RGBB.

Pin D3 through D7 are JTAG interface pins. These can be used to reprogram your P1 bootloader or user firmware image with standard JTAG tools such as the ST-Link v2, J-Link, R-Link, OLIMEX ARM-USB-TINI-H, and also the FTDI-based Particle JTAG Programmer. If you are short on available pins, you may also use SWD mode which requires less connections.

Photon Pin	JTAG	SWD	STM32F205RGY6 Pin	P1 Pin #	P1 Pin Name	Default Internal <sup>[1]</sup>
D7	JTAG_TMS	SWD/SWDIO	PA13	54	MICRO_JTAG_TMS	~40k pull-up
D6	JTAG_TCK	CLK/SWCLK	PA14	55	MICRO_JTAG_TCK	~40k pull-down
D5	JTAG_TDI		PA15	53	MICRO_JTAG_TDI	~40k pull-up
D4	JTAG_TDO		PB3	52	MICRO_JTAG_TDO	Floating
D3	JTAG_TRST		PB4	51	MICRO_JTAG_TRSTN	~40k pull-up
3V3	Power	Power				
GND	Ground	Ground				
RST	Reset	Reset				

**Notes:** <sup>[1]</sup> Default state after reset for a short period of time before these pins are restored to GPIO (if JTAG debugging is not required, i.e. `USE_SWD_JTAG=y` is not specified on the command line.)

A standard 20-pin 0.1" shrouded male JTAG interface connector should be wired as follows:



(click to stop squinting)

## EXTERNAL COEXISTENCE INTERFACE

---

**Note:** This interface is not supported by the P1 module and cannot be used.

When two radios occupying the same frequency band are used in the same system, such as Wi-Fi and Bluetooth, a coexistence interface can be used to coordinate transmit activity, to ensure optimal performance by arbitrating conflicts between the two radios.

P1 Pin Name	P1 Pin #	I/O	Description
BTCX_RF_ACTIVE	57	I	Coexistence signal: Bluetooth is active
BTCX_STATUS	56	I	Coexistence signal: Bluetooth priority status and TX/RX direction
BTCX_TXCONF	58	O	Output giving Bluetooth permission to TX

When these pins are programmed to be used as a Bluetooth coexistence interface, they're set as high impedance on power up and reset.

# Memory Map

## STM32F205RGY6 FLASH LAYOUT OVERVIEW

---

- Bootloader (16 KB)
- DCT1 (16 KB), stores Wi-Fi credentials, keys, mfg info, system flags, etc..
- DCT2 (16 KB), swap area for DCT1
- EEPROM emulation bank 1 (16 KB)
- EEPROM emulation bank 2 (64 KB)
- Device OS (512 KB) [256 KB Wi-Fi/comms + 256 KB hal/platform/services]
- Factory backup, OTA backup and user application (384 KB) [3 x 128 KB]

## DCT LAYOUT

---

The DCT area of flash memory has been mapped to a separate DFU media device so that we can incrementally update the application data. This allows one item (say, server public key) to be updated without erasing the other items.

DCT layout in `release/stable` [found here in firmware.](#)

Region	Offset	Size
system flags	0	32
version	32	2
device private key	34	1216
device public key	1250	384
ip config	1634	120
feature flags	1754	4
country code	1758	4
claim code	1762	63
claimed	1825	1
ssid prefix	1826	26
device code	1852	6
version string	1858	32
dns resolve	1890	128
reserved1	2018	64
server public key	2082	768
padding	2850	2
flash modules	2852	100
product store	2952	24
antenna selection	2976	1
cloud transport	2977	1
alt device public key	2978	128
alt device private key	3106	192
alt server public key	3298	192
alt server address	3490	128
device id	3618	12
radio flags	3630	1
mode button mirror	3631	32

led mirror	3663	96
led theme	3759	64
reserved2	3823	435

**Note:** Writing 0xFF to offset 34 (DEFAULT) or 3106 (ALTERNATE) will cause the device to re-generate a new private key on the next boot. Alternate keys are currently unsupported on the P1 but are used on the Electron as UDP/ECC keys. You should not need to use this feature unless your keys are corrupted.

```
// Regenerate Default Keys
echo -en "\xFF" > fillbyte && dfu-util -d 2b04:d00a -a 1 -s 34 -D fillbyte
// Regenerate Alternate Keys
echo -en "\xFF" > fillbyte && dfu-util -d 2b04:d00a -a 1 -s 3106 -D
fillbyte
```

#### MEMORY MAP (COMMON)

Region	Start Address	End Address	Size
Bootloader	0x8000000	0x8004000	16 KB
DCT1	0x8004000	0x8008000	16 KB
DCT2	0x8008000	0x800C000	16 KB
EEPROM1	0x800C000	0x8010000	16 KB
EEPROM2	0x8010000	0x8020000	64 KB

#### MEMORY MAP (MODULAR FIRMWARE - DEFAULT)

Region	Start Address	End Address	Size
System Part 1	0x8020000	0x8060000	256 KB
System Part 2	0x8060000	0x80A0000	256 KB
User Part	0x80A0000	0x80C0000	128 KB
OTA Backup	0x80C0000	0x80E0000	128 KB
Factory Backup	0x80E0000	0x8100000	128 KB

#### MEMORY MAP (MONOLITHIC FIRMWARE - OPTIONAL)

Region	Start Address	End Address	Size
Firmware	0x8020000	0x8080000	384 KB
Factory Reset	0x8080000	0x80E0000	384 KB
Unused (factory reset modular)	0x80E0000	0x8100000	128 KB



# Pin and button definition

## PIN MARKINGS



## PIN DESCRIPTION

Pin	Description
RST	Active-low reset input. On-board circuitry contains a 1k ohm pull-up resistor between RST and 3V3, and 0.1uF capacitor between RST and GND.
VBAT	Supply to the internal RTC, backup registers and SRAM when 3V3 not present (1.65 to 3.6VDC).
3V3	This pin represents the regulated +3.3V DC power to the P1 module. In reality, +3.3V must be supplied to 3 different inputs: VBAT_WL (pin 2 & 3), VDDIO_3V3_WL (pin 5), VDD_3V3 (pin 26 & 27). Optionally +3.3V may be supplied to VBAT_MICRO (pin 38) for data retention in low power sleep modes. Each of these inputs also requires a 0.1uF and 10uF ceramic decoupling capacitor, located as close as possible to the pin.
TX	Primarily used as UART TX, but can also be used as a digital GPIO or PWM <sup>[1]</sup> .
RX	Primarily used as UART RX, but can also be used as a digital GPIO or PWM <sup>[1]</sup> .
WKP	Active-high wakeup pin, wakes the module from sleep/standby modes. When not used as a WAKEUP, this pin can also be used as a digital GPIO, ADC input or PWM <sup>[1]</sup> . Can be referred to as <b>A7</b> when used as an ADC.
DAC	12-bit Digital-to-Analog (D/A) output (0-4095), referred to as <b>DAC</b> or <b>DAC1</b> in software. Can also be used as a digital GPIO or ADC. Can be referred to as <b>A6</b> when used as an ADC. A3 is a second DAC output used as <b>DAC2</b> in software.
A0~A7	12-bit Analog-to-Digital (A/D) inputs (0-4095), and also digital GPIOs. <b>A6</b> and <b>A7</b> are code convenience mappings, which means pins are not actually labeled as such but you may use code like <code>analogRead(A7)</code> . <b>A6</b> maps to the DAC pin and <b>A7</b> maps to the WKP pin. A4,A5,A7 may also be used as a PWM <sup>[1]</sup> output.
D0~D7	Digital only GPIO pins. D0~D3 may also be used as a PWM <sup>[1]</sup> output.
P1S0	12-bit Analog-to-Digital (A/D) inputs (0-4095), and also can be used as a digital GPIO or PWM <sup>[1]</sup> .
P1S1	12-bit Analog-to-Digital (A/D) inputs (0-4095), and also can be used as a digital GPIO or PWM <sup>[1]</sup> .
P1S2	12-bit Analog-to-Digital (A/D) inputs (0-4095), and also can be used as a digital GPIO.
P1S3	12-bit Analog-to-Digital (A/D) inputs (0-4095), and also can be used as a digital GPIO.
P1S4	Primarily used as a digital GPIO.
P1S5	12-bit Analog-to-Digital (A/D) inputs (0-4095), and also can be used as a digital GPIO.

P1S6 Can be used as a digital GPIO or PWM<sup>[1]</sup> output. Must disable Wi-Fi Powersave Clock first, see System Features in Firmware Reference.

**Notes:** <sup>[1]</sup> PWM is available on D0, D1, D2, D3, A4, A5, WKP, RX, TX, P1S0, P1S1, P1S6 with a caveat: PWM timer peripheral is duplicated on two pins (A5/D2) and (A4/D3) for 10 total independent PWM outputs. For example: PWM may be used on A5 while D2 is used as a GPIO, or D2 as a PWM while A5 is used as an analog input. However A5 and D2 cannot be used as independently controlled PWM outputs at the same time. P1S6 requires System Feature Wi-Fi Powersave Clock to be disabled. See System Features in Firmware Reference.

## PINOUT DIAGRAM

USB	Pin	Exposed Functions				STM32 Pin	P1 Pin #	P1 Pin Name	
P1	3V3	3V3							
	RST	RST					E8	34	MICRO_RST_N
	VBAT	VBAT					A9	38	VBAT
	GND	GND							
	D7	JTAG_TMS					PA13	54	MICRO_JTAG_TMS
	D6	JTAG_TCK					PA14	55	MICRO_JTAG_TCK
	D5	JTAG_TDI	SPI1 (SS)			I2S3_WS	PA15	53	MICRO_JTAG_TDI
	D4	JTAG_TDO	SPI1 (SCK)			I2S3_SCK	PB3	52	MICRO_JTAG_TDO
	D3	JTAG_TRST	SPI1 (MISO)	TIM3_CH1		PB4	51	MICRO_JTAG_TRSTN	
	D2		SPI1 (MOSI)	CAN2_RX	TIM3_CH2	I2S3_SD	PB5	45	MICRO_GPIO_7
	D1	SCL		CAN2_TX	TIM4_CH1		PB6	35	MICRO_I2C1_SCL
	D0	SDA			TIM4_CH2		PB7	36	MICRO_I2C1_SDA
Pin	USB	Exposed Functions				STM32 Pin	P1 Pin #	P1 Pin Name	
P1	VIN	VIN							
	GND	GND							
	TX		USART1_TX	TIM1_CH2		PA9	64	MICRO_UART1_TXD	
	RX		USART1_RX	TIM1_CH3		PA10	63	MICRO_UART1_RXD	
	WKP	ADC0		TIM5_CH1		PA0	30	MICRO_UART2_CTS	
	DAC	ADC4			DAC1	PA4	24	MICRO_SPI1_SS <sup>[2]</sup>	
	A5	ADC7	SPI (MOSI)	TIM3_CH2		PA7	23	MICRO_SPI1_MOSI	
	A4	ADC6	SPI (MISO)	TIM3_CH1		PA6	21	MICRO_SPI1_MISO	
	A3	ADC5	SPI (SCK)		DAC2	PA5	22	MICRO_SPI1_SCK	
	A2	ADC12	SPI (SS)			PC2	49	MICRO_GPIO_13	
	A1	ADC13				PC3	43	MICRO_GPIO_5	
	A0	ADC15				PC5	50	MICRO_GPIO_14	
User I/O		Exposed Functions				STM32 Pin	P1 Pin #	P1 Pin Name	
P1	RGB LED - RED			TIM2_CH2		PA1	29	MICRO_UART2_RTS	
	RGB LED - GREEN			TIM2_CH3		PA2	32	MICRO_UART2_TXD	
	RGB LED - BLUE			TIM2_CH4		PA3	31	MICRO_UART2_RXD	
	Setup Button			TIM3_CH2	I2S3_MCK	PC7	46	MICRO_GPIO_8	
	Reset Button					E8	34	MICRO_RST_N	
	USB Data+					PA12	61	MICRO_UART1_RTS	
	USB Data-					PA11	62	MICRO_UART1_CTS	
	P1S0		ADC8	TIM3_CH3		PB0	40	MICRO_GPIO_1	
	P1S1		ADC9	TIM3_CH4		PB1	41	MICRO_GPIO_2	
	P1S2		ADC10			PC0	42	MICRO_GPIO_3	
	P1S3		ADC14			PC4	44	MICRO_GPIO_6	
	P1S4					PC13	47	MICRO_GPIO_9	
	P1S5		ADC11			PC1	48	MICRO_GPIO_12	
	P1S6 <sup>[1]</sup>			TIM1_CH1		PA8	33	TESTMODE	
	Peripheral Key		ADC	SPI	PWM/Servo/Tone				
			JTAG	SPI1	I2S	DAC			
			I2C/Wire	Serial1	CAN				

You can download a high resolution pinout diagram in a [PDF version here.](#)

**Notes:** <sup>[1]</sup> Connected to MCO1 by default, outputs 32kHz clock for WICED powersave mode. See System Features in the Firmware Reference to disable the Wi-Fi Powersave Clock and allow usage of this pin.

<sup>[2]</sup> MICRO\_SPI1\_SS is only for reference as a P1 module pin name. It is technically speaking the STM32 pin PA4 which is the SS pin in an hardware SPI driven sense, however in the Particle API SPI SS is only user controlled as a GPIO. The hardware SS pin is not implemented. The default SS pin for the Particle SPI API is A2 (STM32 pin PC2), but any GPIO can be used for this function with `SPI.begin(pin)`.

#### COMPLETE P1 MODULE PIN LISTING

P1 Pin #	P1 Pin Name	Type / STM32F205RGY6	Description
		Port	
1	GND	PWR	Ground
2~3	VBAT_WL	PWR	+3.3V
4	GND	PWR	Ground
5	VDDIO_3V3_WL	PWR	+3.3V
6	GND	PWR	Ground
7	WL_REG_ON	PWR	BCM43362 Debugging Pin
8~12	NC	NC	NC
13	GND	PWR	Ground
14	NC	NC	NC
15	GND	PWR	Ground
16	WL_JTAG_TDI	DEBUG	BCM43362 Debugging Pin
17	WL_JTAG_TCK	DEBUG	BCM43362 Debugging Pin
18	WL_JTAG_TRSTN	DEBUG	BCM43362 Debugging Pin
19	WL_JTAG_TMS	DEBUG	BCM43362 Debugging Pin
20	WL_JTAG_TDO	DEBUG	BCM43362 Debugging Pin
21	MICRO_SPI1_MISO	PA6	A4 (SPI MISO)
22	MICRO_SPI1_SCK	PA5	A3 (SPI SCK)
23	MICRO_SPI1_MOSI	PA7	A5 (SPI MOSI)
24	MICRO_SPI1_SS	PA4	DAC
25	GND	PWR	Ground
26~27	VDD_3V3	PWR	+3.3V
28	GND	PWR	Ground
29	MICRO_UART2_RTS	PA1	RGBR (RGB LED RED)
30	MICRO_UART2_CTS	PA0	WKP
31	MICRO_UART2_RXD	PA3	RGBB (RGB LED BLUE)
32	MICRO_UART2_TXD	PA2	RGBG (RGB LED GREEN)
33	TESTMODE	PA8	PIS6 (Connected to MCO1 by default, outputs 32kHz clock for WICED powersave mode. See System Features in the Firmware Reference to disable the Wi-Fi Powersave Clock and allow usage of this pin.)
34	MICRO_RST_N	I	/RESET (Active low MCU reset)
35	MICRO_I2C1_SCL	PB6	D1 (I2C SCL)

36	MICRO_I2C1_SDA	PB7	D0 (I2C SDA)
37	GND	PWR	Ground
38	VBAT_MICRO	PWR	Supply to the internal RTC, backup registers and SRAM when 3V3 not present (1.65 to 3.6VDC)
39	GND	PWR	Ground
40	MICRO_GPIO_1	PB0	P1S0
41	MICRO_GPIO_2	PB1	P1S1
42	MICRO_GPIO_3	PC0	P1S2
43	MICRO_GPIO_5	PC3	A1
44	MICRO_GPIO_6	PC4	P1S3
45	MICRO_GPIO_7	PB5	D2 (I2S SD)
46	MICRO_GPIO_8	PC7	/SETUP (I2S MCK)
47	MICRO_GPIO_9	PC13	P1S4
48	MICRO_GPIO_12	PC1	P1S5
49	MICRO_GPIO_13	PC2	A2 (DEFAULT SPI SS)
50	MICRO_GPIO_14	PC5	A0
51	MICRO_JTAG_TRSTN	PB4	D3
52	MICRO_JTAG_TDO	PB3	D4 (I2S SCK)
53	MICRO_JTAG_TDI	PA15	D5 (I2S WS)
54	MICRO_JTAG_TMS	PA13	D7
55	MICRO_JTAG_TCK	PA14	D6
56	BTCX_STATUS	I	Coexistence signal: Bluetooth status and TX/RX direction
57	BTCX_RF_ACTIVE	I	Coexistence signal: Bluetooth is active
58	BTCX_TXCONF	O	Output giving Bluetooth permission to TX
59	GND	PWR	Ground
60	WL_SLEEP_CLK	DEBUG	BCM43362 Debugging Pin
61	MICRO_UART1_RTS	PA12	OTG_FS_DP (USB D+)
62	MICRO_UART1_CTS	PA11	OTG_FS_DM (USB D--)
63	MICRO_UART1_RXD	PA10	RX
64	MICRO_UART1_TXD	PA9	TX
65~73	GND	PWR	Ground
74	PAD1	NC	NC
75	PAD2	NC	NC

# Technical specification

## ABSOLUTE MAXIMUM RATINGS

Parameter	Symbol	Min	Typ	Max	Unit
Supply Input Voltage	V <sub>3V3-MAX</sub>			+3.6	V
Storage Temperature	T <sub>stg</sub>	-40		+85	°C
ESD Susceptibility HBM (Human Body Mode)	V <sub>ESD</sub>			2	kV

## RECOMMENDED OPERATING CONDITIONS

Parameter	Symbol	Min	Typ	Max	Unit
Supply Input Voltage	V <sub>3V3</sub> <sup>[1]</sup>	+3.0	+3.3	+3.6	V
Supply Input Current (VBAT_WL)	I <sub>VBAT_WL</sub>			310	mA
Supply Input Current (VDDIO_3V3_WL)	I <sub>VDDIO_3V3_WL</sub>			50	mA
Supply Input Current (VDD_3V3)	I <sub>VDD_3V3</sub>			120	mA
Supply Input Voltage	V <sub>VBAT_MICRO</sub>	+1.65		+3.6	V
Supply Input Current (VBAT_MICRO)	I <sub>VBAT_MICRO</sub>			19	uA
Operating Current (Wi-Fi on)	I <sub>3V3 avg</sub> <sup>[1]</sup>		80	100	mA
Operating Current (Wi-Fi on)	I <sub>3V3 pk</sub> <sup>[1]</sup>	235 <sup>[2]</sup>		430 <sup>[2]</sup>	mA
Operating Current (Wi-Fi on, w/powersave)	I <sub>3V3 avg</sub> <sup>[1]</sup>		18	100 <sup>[3]</sup>	mA
Operating Current (Wi-Fi off)	I <sub>3V3 avg</sub> <sup>[1]</sup>		30	40	mA
Sleep Current (5V @ VIN)	I <sub>Qs</sub>		1	2	mA
Deep Sleep Current (5V @ VIN)	I <sub>Qds</sub>		80	100	uA
Operating Temperature	T <sub>op</sub>	-20		+60	°C
Humidity Range Non condensing, relative humidity				95	%

### Notes:

<sup>[1]</sup> V<sub>3V3</sub> and I<sub>3V3</sub> represents the the combined 4 inputs that require +3.3V: VBAT\_WL, VDDIO\_3V3\_WL, VDD\_3V3 and VBAT\_MICRO.

<sup>[2]</sup> These numbers represent the extreme range of short peak current bursts when transmitting and receiving in 802.11b/g/n modes at different power levels. Average TX current consumption in will be 80-100mA.

<sup>[3]</sup> These are very short average current bursts when transmitting and receiving. On average if minimizing frequency of TX/RX events, current consumption in powersave mode will be 18mA

## WI-FI SPECIFICATIONS

Feature	Description
WLAN Standards	IEEE 802.11b/g/n
Antenna Port	Single Antenna
Frequency Band	2.412GHz -- 2.462GHz (United States of America and Canada) 2.412GHz -- 2.472GHz (EU)
Sub Channels	1 -- 11 (United States of America and Canada) 1 -- 13 (EU)

Modulation	DSSS, CCK, OFDM, BPSK, QPSK, 16QAM, 64QAM
------------	---

P1 module Wi-Fi output power		Typ.	Tol.	Unit
RF Average Output Power, 802.11b CCK Mode	1M	Avail. upon request	+/- 1.5	dBm
	11M	-	+/- 1.5	dBm
RF Average Output Power, 802.11g OFDM Mode	6M	-	+/- 1.5	dBm
	54M	-	+/- 1.5	dBm
RF Average Output Power, 802.11n OFDM Mode	MCS0	-	+/- 1.5	dBm
	MCS7	-	+/- 1.5	dBm

## I/O CHARACTERISTICS

These specifications are based on the STM32F205RGY6 datasheet, with reference to Photon pin nomenclature.

Parameter	Symbol	Conditions	Min	Typ	Max	Unit
Standard I/O input low level voltage	$V_{IL}$		-0.3		$0.28 \cdot (V_{3V3} - 2) + 0.8$	V
I/O FT <sup>[1]</sup> input low level voltage	$V_{IL}$		-0.3		$0.32 \cdot (V_{3V3} - 2) + 0.75$	V
Standard I/O input high level voltage	$V_{IH}$		$0.41 \cdot (V_{3V3} - 2) + 1.3$		$V_{3V3} + 0.3$	V
I/O FT <sup>[1]</sup> input high level voltage	$V_{IH}$	$V_{3V3} > 2V$	$0.42 \cdot (V_{3V3} - 2) + 1$		5.5	V
	$V_{IH}$	$V_{3V3} \leq 2V$	$0.42 \cdot (V_{3V3} - 2) + 1$		5.2	V
Standard I/O Schmitt trigger voltage hysteresis <sup>[2]</sup>	$V_{hys}$		200			mV
I/O FT Schmitt trigger voltage hysteresis <sup>[2]</sup>	$V_{hys}$		5% $V_{3V3}$ <sup>[3]</sup>			mV
Input/Output current max	$I_{io}$				±25	mA
Input/Output current total	$I_{io \text{ total}}$				±120	mA
Input leakage current <sup>[4]</sup>	$I_{lkg}$	$GND \leq V_{io} \leq V_{3V3}$ GPIOs			±1	µA
Input leakage current <sup>[4]</sup>	$I_{lkg}$	$R_{PU}$		$V_{io} = 5V$ , I/O FT	3	µA
Weak pull-up equivalent resistor <sup>[5]</sup>	$R_{PU}$	$V_{io} = GND$	30	40	50	kΩ
Weak pull-down equivalent resistor <sup>[5]</sup>	$R_{PD}$	$V_{io} = V_{3V3}$	30	40	50	kΩ
I/O pin capacitance	$C_{IO}$			5		pF
DAC output voltage (buffers enabled by default)	$V_{DAC}$		0.2		$V_{3V3} - 0.2$	V
DAC output resistive load (buffers enabled by default)	$R_{DAC}$		5			kΩ
DAC output capacitive load (buffers enabled by default)	$C_{DAC}$				50	pF

### Notes:

<sup>[1]</sup> FT = Five-volt tolerant. In order to sustain a voltage higher than  $V_{3V3} + 0.3$  the internal pull-up/pull-down resistors must be disabled.

<sup>[2]</sup> Hysteresis voltage between Schmitt trigger switching levels. Based on characterization, not tested in production.

[3] With a minimum of 100mV.


[4] Leakage could be higher than max. if negative current is injected on adjacent pins.

[5] Pull-up and pull-down resistors are designed with a true resistance in series with switchable PMOS/NMOS. This PMOS/NMOS contribution to the series resistance is minimum (~10% order).

# Mechanical specifications

## OVERALL DIMENSIONS

P1 module dimensions are: 0.787"(28mm) (W) x 1.102"(20mm) (L) x 0.0787"(2.0mm) (H) +/-0.0039" (0.1mm) (includes metal shielding)



## P1 MODULE DIMENSIONS


These are the physical dimensions of the P1 module itself, including all pins:





## P1 MODULE RECOMMENDED PCB LAND PATTERN


The P1 can be mounted directly on a carrier PCB with following PCB land pattern:




A P1 part for EAGLE can be found in the [Particle EAGLE library](#)

# P1 Reference Design Schematic


## SCHEMATIC - USB




## SCHEMATIC - POWER



## SCHEMATIC - USER I/O



## SCHEMATIC - P1 WI-FI MODULE



# P1 Reference Design Layout

## **P1 REFERENCE DESIGN TOP LAYER (GTL)**

---


To be added.

## **P1 REFERENCE DESIGN BOTTOM LAYER (GBL)**

---

To be added.

# Recommended solder reflow profile



Phase	Temperatures and Rates
A-B.	Ambient~150°C, Heating rate: < 3°C/s
B-C.	150~200°C,soak time: 60~120 s
C-D.	200~245°C, Heating rate: < 3°C/s
D.	Peak temp.: 235~245°C, Time above 220°C: 40~90 s
D-E.	245~220°C, Cooling rate: < 1°C/s

# Ordering information

P1 modules are available from [store.particle.io](https://store.particle.io) as cut tape in quantities of 10 each.

SKU	Description	Region	Lifecycle	Replacement
P1MOD10	P1 Wi-Fi Module, Cut tape [x10]	Global	GA	
P1REEL	P1 Wi-Fi Module, Reel [x500]	Global	Deprecated	

## Qualification and approvals



- RoHS
- CE
- FCC ID: COFWMNBM11
- IC: 10293A-WMNBM11

# Product handling

## TAPE AND REEL INFO



## MOISTURE SENSITIVITY LEVELS

The Moisture Sensitivity Level (MSL) relates to the packaging and handling precautions required. The P1 module is rated level 3. In general, this precaution applies for Photons without headers. When reflowing a P1 directly onto an application PCB, increased moisture levels prior to reflow can damage sensitive electronics on the P1. A bake process to reduce moisture may be required.

For more information regarding moisture sensitivity levels, labeling, storage and drying see the MSL standard see IPC/JEDEC J-STD-020 (can be downloaded from [www.jedec.org](http://www.jedec.org)).

## ESD PRECAUTIONS

The P1 module contains highly sensitive electronic circuitry and is an Electrostatic Sensitive Device (ESD). Handling a P1 module without proper ESD protection may destroy or damage it permanently. Proper ESD handling and packaging procedures must be applied throughout the processing, handling and operation of any application that incorporates P1 modules. ESD precautions should be implemented on the application board where the P1 module is mounted. Failure to observe these precautions can result in severe damage to the P1 module!

## Default settings

The P1 module comes pre-programmed with a bootloader and a user application called Tinker. This application works with an iOS and Android app also named Tinker that allows you to very easily toggle digital pins, take analog and digital readings and drive variable PWM outputs.

The bootloader allows you to easily update the user application via several different methods, USB, OTA, Serial Y-Modem, and also internally via the Factory Reset procedure. All of these methods have multiple tools associated with them as well.

You may use the [Particle Web IDE](#) to code, compile and flash a user application OTA (Over The Air). [Particle Workbench](#) is a full-featured desktop IDE for Windows, Mac, and Linux based on VSCode and supports both cloud-based and local gcc-arm compiles. The [Particle CLI](#) provides a command-line interface for cloud-based compiles and flashing code over USB.



# Glossary

Radio Frequency

## **SMT**

Surface Mount Technology (often associated with SMD which is a surface mount device).

## **AP**

Access Point

## **USB**

Universal Serial Bus

## **Quiescent current**

Current consumed in the deepest sleep state

## **FT**

Five-tolerant; Refers to a pin being tolerant to 5V.

## **3V3**

+3.3V; The regulated +3.3V supply rail. Also used to note a pin is only 3.3V tolerant.

## **RTC**

Real Time Clock

## **OTA**

Over The Air; describing how firmware is transferred to the device.

# FCC IC CE Warnings and End Product Labeling Requirements

**Federal Communication Commission Interference Statement** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**FCC Caution:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

**FCC Radiation Exposure Statement:** This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter module must not be co-located or operating in conjunction with any other antenna or transmitter. This End equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

**IMPORTANT NOTE:** In the event that these conditions can not be met (for example certain laptop configurations or co-location with another transmitter), then the FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

**End Product Labeling** The final end product must be labeled in a visible area with the following:

Contains FCC ID: COFWMNBM11

**Manual Information to the End User** The OEM integrator has to be aware not to provide information to the end user regarding how to install or remove this RF module in the user's manual of the end product which integrates this module.

**Canada Statement** This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

1. This device may not cause interference; and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

**L'exploitation est autorisée aux deux conditions suivantes:**

1. l'appareil ne doit pas produire de brouillage;
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

**Caution Exposure:** This device meets the exemption from the routine evaluation limits in section 2.5 of RSS102 and users can obtain Canadian information on RF exposure and compliance. Le dispositif répond à l'exemption des limites d'évaluation de routine dans la section 2.5 de RSS102 et les utilisateurs peuvent obtenir des renseignements canadiens sur l'exposition aux RF et le respect.

**The final end product must be labelled in a visible area with the following:** The Industry Canada certification label of a module shall be clearly visible at all times when installed in the host device, otherwise the host device must be labelled to display the Industry Canada certification number of the module, preceded by the words "Contains transmitter module", or the word "Contains", or similar wording expressing the same meaning, as follows:

Contains transmitter module IC: 20127-PHOTON

This End equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

The end user manual shall include all required regulatory information/warning as shown in this manual.

# Revision history

Revision	Date	Author	Comments
v001	4-May-2015	BW	Initial release
v002	31-May-2015	BW	Update assets
v003	1-June-2015	BW	Updated VBAT_MICRO info
v004	24-July-2015	BW	Added FCC IC CE Warnings and End Product Labeling Requirements, Updated power output, added approved antennas, Corrected DAC2 as A3, Corrected A0 as pin 50, Corrected External Coexistence Interface pin numbers, Added RGB LED, SETUP and RESET button section.
v005	11-April-2016	BW	Added: full STM32 part number, Memory map, DAC limits, SWD pin locations, max source/sink current, known errata URL and tape-and-reel dimensions. Updated: BT COEX info, pinout diagrams (fixed RESET pin number error), operating conditions, pin descriptions (P1S0~P1S5 pins), land-pattern image signal keepout note.
v006	14-July-2016	BW	Updated P1 pin listing: TESTMODE pin 33 (PA8), connected to MCO1 by default, outputs 32kHz clock for WICED powersave mode - currently unsupported for user control.
v007	20-September-2016	BW	Updated P1 pin listing: TESTMODE pin 33 (PA8), can use now as P1S6 if enabled. Updated Pinmap and added P1S6. Updated Pin Description and Peripherals and GPIO.
v008	25-July-2017	BW	Added note to clarify MICRO_SPI1_SS label, renamed SPI1_*/SPI3_* to match Particle API instead of STM32 pin names to avoid confusion (now SPI and SPI1), updated the Pin Description section and added high resolution pinout PDF, updated PWM notes, JTAG_TDO pin number (54 -> 52), block diagram and DCT layout, added warning to power section
v009	30-August-2017	BW	Added part number for 1MB external SPI flash (MX25L8006E)
v010	31-May-2018	BW	Updated External Coexistence Interface section (unsupported)
v011	09-Dec-2020	RK	Remove paid tiers limit
v012	15-Mar-2021	RK	Updated ordering information
v013	14-Mar-2023	RK	Added deprecation notice

## Known Errata

We are tracking [known errata with this datasheet here](#). These issues/errors in the datasheet will be resolved in subsequent revisions.

# Contact

## Web

<https://www.particle.io>

## Community Forums

<https://community.particle.io>

## Email

<https://support.particle.io>