









## Knob401

Note for reference only and use the pins #'s in the root page of the schematic. Reason pin 7 and 8 were swapped: to get proper phasing of this sense loop.

Sheet: /Antenna Diagram/ File: antenna_diagram.kicad_sch	
<b>Title: SignalSnagger</b>	
Size: A4	Date: 2024-07-12
KiCad E.D.A. kicad (6.0.4-0)	Rev: <b>0.325</b> Id: 4/4