







Note for reference only and use
the pins #'s in the root page of
the schematic. Reason pin 7 and 8
were swapped: to get proper
phasing of this sense loop.

Sheet: /Antenna Diagram/
File: antenna_diagram.kicad_sch

Title: SignalSnagger

Size: A4 Date: 2024-06-09

KiCad E.D.A. kicad (6.0.4-0)

Rev: 0.321

Id: 4/4