




Clock and Reset




PLL Config




AUX Config




AUX OUTPUT (8 Channels)




UART to LMX25 (Configuration-Data)




UART to LMX25 (UART-Communication to Boards)




8CH OUTPUT XLR DA-Boards (16 Channels)




8CH INPUT XLR AD-Boards (32 Channel)




Audio Routing Matrix




Audio Routing Matrix




P16 / UltraNet Output (16 Channels)



8CH INPUT EXPANSIONCARD (32 Channel)



AUX INPUT (8 Channel)



8CH OUTPUT EXPANSIONCARD (32 Channels)

