






















































































Frenchwood® Patio Door Transom Sash-Set

Rough Opening	2'-1"	2'-7"	2'-9"	3'-1"	3'-3"	4'-0"	5'-0"	5'-4"	6'-0"	6'-4"
	(635)	(787)	(838)	(940)	(991)	(1219)	(1524)	(1626)	(1829)	(1930)
Unit Dimension	2'-0 ¹ / ₈ "	2'-6 ¹ / ₈ "	2'-8 ¹ / ₈ "	3'-0 ¹ / ₈ "	3'-2 ¹ / ₈ "	3'-11 ¹ / ₄ "	4'-11 ¹ / ₄ "	5'-3 ¹ / ₄ "	5'-11 ¹ / ₄ "	6'-3 ¹ / ₄ "
	(613)	(765)	(816)	(918)	(968)	(1200)	(1505)	(1607)	(1810)	(1911)
Frenchwood® Patio Door Transom - Sash Set (FWTD-1)										
1'-0"										
1'-4"										
1'-8"										
2'-0"										
2'-4"										
2'-8"										

Frenchwood® Patio Door Transom Sash-Set

Rough Opening	7'-0"	7'-11"	8'-0"	8'-11"	9'-6"
	(2134)	(2413)	(2438)	(2718)	(2896)
Unit Dimension	6'-11 ¹ / ₄ "	7'-10 ¹ / ₁₆ "	7'-11 ¹ / ₄ "	8'-10 ¹ / ₁₆ "	9'-4 ¹ / ₁₆ "
	(2115)	(2399)	(2419)	(2704)	(2856)
Frenchwood® Patio Door Transom - Sash Set (FWTD-1)					
1'-0"					
1'-4"					
1'-8"					
2'-0"					
2'-4"					

Notes:

"Unit Dimension" always refers to outside frame to frame dimension.
 "Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.
 Dimensions in parentheses are in millimeters.


Date: 11/07/16
 Scale: 1/8" (3) = 1' (305)

Frenchwood® Patio Door Twin Transom Sash-Set


		4'-0"	5'-0"	5'-4"	6'-0"	6'-4"
		(1219)	(1524)	(1626)	(1829)	(1930)
		3'-11 $\frac{1}{4}$ "	4'-11 $\frac{1}{4}$ "	5'-3 $\frac{3}{4}$ "	5'-11 $\frac{1}{4}$ "	6'-3 $\frac{3}{4}$ "
		(1200)	(1505)	(1607)	(1810)	(1911)
Rough Opening	Unit					
	Dimension					
1'-0"	1'-0"					
1'-4"	1'-4"					
1'-8"	1'-8"					
2'-0"	2'-0"					
2'-4"	2'-4"					
2'-8"	2'-8"					
3'-0"	3'-0"					
3'-4"	3'-4"					
3'-8"	3'-8"					
4'-0"	4'-0"					
4'-4"	4'-4"					
4'-8"	4'-8"					
5'-0"	5'-0"					
5'-4"	5'-4"					
5'-8"	5'-8"					
6'-0"	6'-0"					
6'-4"	6'-4"					
6'-8"	6'-8"					
7'-0"	7'-0"					
7'-4"	7'-4"					
7'-8"	7'-8"					
8'-0"	8'-0"					
8'-4"	8'-4"					
8'-8"	8'-8"					
9'-0"	9'-0"					
9'-4"	9'-4"					
9'-8"	9'-8"					
10'-0"	10'-0"					
10'-4"	10'-4"					
10'-8"	10'-8"					
11'-0"	11'-0"					
11'-4"	11'-4"					
11'-8"	11'-8"					
12'-0"	12'-0"					
12'-4"	12'-4"					
12'-8"	12'-8"					
13'-0"	13'-0"					
13'-4"	13'-4"					
13'-8"	13'-8"					
14'-0"	14'-0"					
14'-4"	14'-4"					
14'-8"	14'-8"					
15'-0"	15'-0"					
15'-4"	15'-4"					
15'-8"	15'-8"					
16'-0"	16'-0"					
16'-4"	16'-4"					
16'-8"	16'-8"					
17'-0"	17'-0"					
17'-4"	17'-4"					
17'-8"	17'-8"					
18'-0"	18'-0"					
18'-4"	18'-4"					
18'-8"	18'-8"					
19'-0"	19'-0"					
19'-4"	19'-4"					
19'-8"	19'-8"					
20'-0"	20'-0"					
20'-4"	20'-4"					
20'-8"	20'-8"					
21'-0"	21'-0"					
21'-4"	21'-4"					
21'-8"	21'-8"					
22'-0"	22'-0"					
22'-4"	22'-4"					
22'-8"	22'-8"					
23'-0"	23'-0"					
23'-4"	23'-4"					
23'-8"	23'-8"					
24'-0"	24'-0"					
24'-4"	24'-4"					
24'-8"	24'-8"					
25'-0"	25'-0"					
25'-4"	25'-4"					
25'-8"	25'-8"					
26'-0"	26'-0"					
26'-4"	26'-4"					
26'-8"	26'-8"					
27'-0"	27'-0"					
27'-4"	27'-4"					
27'-8"	27'-8"					
28'-0"	28'-0"					
28'-4"	28'-4"					
28'-8"	28'-8"					
29'-0"	29'-0"					
29'-4"	29'-4"					
29'-8"	29'-8"					
30'-0"	30'-0"					
30'-4"	30'-4"					
30'-8"	30'-8"					
31'-0"	31'-0"					
31'-4"	31'-4"					
31'-8"	31'-8"					
32'-0"	32'-0"					
32'-4"	32'-4"					
32'-8"	32'-8"					
33'-0"	33'-0"					
33'-4"	33'-4"					
33'-8"	33'-8"					
34'-0"	34'-0"					
34'-4"	34'-4"					
34'-8"	34'-8"					
35'-0"	35'-0"					
35'-4"	35'-4"					
35'-8"	35'-8"					
36'-0"	36'-0"					
36'-4"	36'-4"					
36'-8"	36'-8"					
37'-0"	37'-0"					
37'-4"	37'-4"					
37'-8"	37'-8"					
38'-0"	38'-0"					
38'-4"	38'-4"					
38'-8"	38'-8"					
39'-0"	39'-0"					
39'-4"	39'-4"					
39'-8"	39'-8"					
40'-0"	40'-0"					
40'-4"	40'-4"					
40'-8"	40'-8"					
41'-0"	41'-0"					
41'-4"	41'-4"					
41'-8"	41'-8"					
42'-0"	42'-0"					
42'-4"	42'-4"					
42'-8"	42'-8"					
43'-0"	43'-0"					
43'-4"	43'-4"					
43'-8"	43'-8"					
44'-0"	44'-0"					
44'-4"	44'-4"					
44'-8"	44'-8"					
45'-0"	45'-0"					
45'-4"	45'-4"					
45'-8"	45'-8"					
46'-0"	46'-0"					
46'-4"	46'-4"					
46'-8"	46'-8"					
47'-0"	47'-0"					
47'-4"	47'-4"					
47'-8"	47'-8"					
48'-0"	48'-0"					
48'-4"	48'-4"					
48'-8"	48'-8"					
49'-0"	49'-0"					
49'-4"	49'-4"					
49'-8"	49'-8"					
50'-0"	50'-0"					
50'-4"	50'-4"					
50'-8"	50'-8"					
51'-0"	51'-0"					
51'-4"	51'-4"					
51'-8"	51'-8"					
52'-0"	52'-0"					
52'-4"	52'-4"					
52'-8"	52'-8"					
53'-0"	53'-0"					
53'-4"	53'-4"					
53'-8"	53'-8"					
54'-0"	54'-0"					
54'-4"	54'-4"					
54'-8"	54'-8"					
55'-0"	55'-0"					
55'-4"	55'-4"					
55'-8"	55'-8"					
56'-0"	56'-0"					
56'-4"	56'-4"					
56'-8"	56'-8"					

A-Series

Frenchwood® Patio Door Sidelight




Frenchwood® Patio Door Sidelight Transom Sash-Set




Andersen®

Frenchwood® Patio Door Sidelight Transom Direct-Set



Frenchwood® Patio Door Venting Transom





















































Notes:


























"Unit Dimension" always refers to outside frame to frame dimension.
 "Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.
 Dimensions in parentheses are in millimeters.

Date: 11/07/16
 Scale: 1/8" (3) = 1' (305)

Frenchwood® Patio Door Transom Direct-Set

Rough Opening	2'-1"	2'-7"	2'-9"	3'-1"	3'-3"	4'-0"	5'-0"	5'-4"	6'-0"	6'-4"
	(635)	(787)	(838)	(940)	(991)	(1219)	(1524)	(1626)	(1829)	(1930)
Unit Dimension	2'-0 ¹ / ₈ "	2'-6 ¹ / ₈ "	2'-8 ¹ / ₈ "	3'-0 ¹ / ₈ "	3'-2 ¹ / ₈ "	3'-11 ¹ / ₄ "	4'-11 ¹ / ₄ "	5'-3 ¹ / ₄ "	5'-11 ¹ / ₄ "	6'-3 ¹ / ₄ "
	(613)	(765)	(816)	(918)	(968)	(1200)	(1505)	(1607)	(1810)	(1911)
Frenchwood® Patio Door Transom Direct-Set (FWTDS)										
2'-4"										
2'-0"										
1'-8"										
1'-4"										
1'-0"										

Frenchwood® Patio Door Transom Direct-Set

Rough Opening	7'-0"	7'-11"	8'-0"	8'-11"	9'-6"
	(2134)	(2413)	(2438)	(2718)	(2896)
Unit Dimension	6'-11 ¹ / ₄ "	7'-10 ¹ / ₁₆ "	7'-11 ¹ / ₄ "	8'-10 ¹ / ₁₆ "	9'-4 ¹ / ₁₆ "
	(2115)	(2399)	(2419)	(2704)	(2856)
Frenchwood® Patio Door Transom Direct-Set (FWTDS)					
2'-4"					
2'-0"					
1'-8"					
1'-4"					
1'-0"					

Notes:

Unit Dimension always refers to outside frame to frame dimension.

Rough Opening dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.

Dimensions in parentheses are in millimeters.

Date: 11/07/16

Scale: 1/8" (3) = 1' (305)