

# 400 SERIES

## Woodwright® Double-Hung Full-Frame Reverse Cottage Windows



Rough Opening		1'-10 <sup>7</sup> / <sub>8</sub> " (562)	2'-2 <sup>1</sup> / <sub>8</sub> " (664)	2'-6 <sup>1</sup> / <sub>8</sub> " (765)	2'-8 <sup>3</sup> / <sub>8</sub> " (816)	2'-10 <sup>1</sup> / <sub>8</sub> " (867)	3'-0 <sup>1</sup> / <sub>8</sub> " (918)	3'-2 <sup>1</sup> / <sub>8</sub> " (968)	3'-6 <sup>1</sup> / <sub>8</sub> " (1070)	3'-10 <sup>1</sup> / <sub>8</sub> " (1172)
Unit Dimension		1'-9 <sup>5</sup> / <sub>8</sub> " (549)	2'-1 <sup>5</sup> / <sub>8</sub> " (651)	2'-5 <sup>5</sup> / <sub>8</sub> " (752)	2'-7 <sup>5</sup> / <sub>8</sub> " (803)	2'-9 <sup>5</sup> / <sub>8</sub> " (854)	2'-11 <sup>5</sup> / <sub>8</sub> " (905)	3'-1 <sup>5</sup> / <sub>8</sub> " (956)	3'-5 <sup>5</sup> / <sub>8</sub> " (1057)	3'-9 <sup>5</sup> / <sub>8</sub> " (1159)
Woodwright® Double-Hung Full-Frame Reverse Cottage Windows (WDH RC)										
3'-0 <sup>5</sup> / <sub>8</sub> " (937)	3'-0 <sup>5</sup> / <sub>8</sub> " (937)									
3'-4 <sup>5</sup> / <sub>8</sub> " (1038)	3'-4 <sup>5</sup> / <sub>8</sub> " (1038)									
3'-8 <sup>5</sup> / <sub>8</sub> " (1140)	3'-8 <sup>5</sup> / <sub>8</sub> " (1140)									
4'-0 <sup>5</sup> / <sub>8</sub> " (1241)	4'-0 <sup>5</sup> / <sub>8</sub> " (1241)									
4'-4 <sup>5</sup> / <sub>8</sub> " (1343)	4'-4 <sup>5</sup> / <sub>8</sub> " (1343)									
4'-8 <sup>5</sup> / <sub>8</sub> " (1445)	4'-8 <sup>5</sup> / <sub>8</sub> " (1445)									
5'-0 <sup>5</sup> / <sub>8</sub> " (1546)	5'-0 <sup>5</sup> / <sub>8</sub> " (1546)									
5'-4 <sup>5</sup> / <sub>8</sub> " (1648)	5'-4 <sup>5</sup> / <sub>8</sub> " (1648)									
5'-8 <sup>5</sup> / <sub>8</sub> " (1749)	5'-8 <sup>5</sup> / <sub>8</sub> " (1749)									
6'-0 <sup>5</sup> / <sub>8</sub> " (1851)	6'-0 <sup>5</sup> / <sub>8</sub> " (1851)									

Taller sizes continue on page 02

### Notes:

"Unit Dimension" always refers to outside frame to frame dimension.

"Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.

Dimensions in parentheses are in millimeters.


♦ Meet or exceed clear opening area of 5.7 sq. ft. or 0.53 m<sup>2</sup>, clear opening width of 20" (508) and clear opening height of 24" (610).

Date: 10/04/16

Scale: 1/8" (3) = 1' (305)

400 SERIES

Woodwright® Double-Hung Full-Frame Reverse Cottage Windows



























































Notes:

"Unit Dimension" always refers to outside frame to frame dimension.  
"Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.  
Dimensions in parentheses are in millimeters.  
♦ Meet or exceed clear opening area of 5.7 sq. ft. or 0.53 m<sup>2</sup>, clear opening width of 20" (508) and clear opening height of 24" (610).

Date: 10/04/16  
Scale: 1/8" (3) = 1' (305)

# 400 SERIES

## Woodwright® Picture Windows (Reverse Cottage Alignment)

Rough Opening	Unit Dimension						
	1'-0 $\frac{1}{2}$ " (318)	3'-2 $\frac{1}{8}$ " (968)	3'-6 $\frac{3}{8}$ " (1070)	3'-11 $\frac{1}{8}$ " (1216)	4'-3 $\frac{7}{8}$ " (1318)	4'-11 $\frac{1}{8}$ " (1521)	5'-7 $\frac{7}{8}$ " (1724)
	1'-0" (305)	3'-1 $\frac{1}{8}$ " (956)	3'-5 $\frac{5}{8}$ " (1057)	3'-11 $\frac{5}{16}$ " (1202)	4'-3 $\frac{3}{16}$ " (1303)	4'-11 $\frac{1}{16}$ " (1507)	5'-7 $\frac{3}{16}$ " (1710)
Woodwright® Picture Window - Reverse Cottage Alignment (WPW)							
4'-0 $\frac{1}{8}$ " (1241)							
4'-4 $\frac{1}{8}$ " (1343)							
4'-8 $\frac{1}{8}$ " (1445)							
5'-0 $\frac{1}{8}$ " (1546)							
5'-4 $\frac{1}{8}$ " (1648)							
5'-8 $\frac{1}{8}$ " (1749)							
6'-0 $\frac{1}{8}$ " (1851)							
6'-4 $\frac{1}{8}$ " (1953)							

### Notes:

"Unit Dimension" always refers to outside frame to frame dimension.

"Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.

Dimensions in parentheses are in millimeters.

Date: 10/04/16

Scale: 1/8" (3) = 1' (305)

# 400 SERIES

## Woodwright® Transom Windows



Rough Opening		1'-10 <sup>7</sup> / <sub>8</sub> " (562)	2'-2 <sup>1</sup> / <sub>8</sub> " (664)	2'-6 <sup>1</sup> / <sub>8</sub> " (765)	2'-8 <sup>1</sup> / <sub>8</sub> " (816)	2'-10 <sup>7</sup> / <sub>8</sub> " (867)	3'-0 <sup>7</sup> / <sub>8</sub> " (918)	3'-2 <sup>7</sup> / <sub>8</sub> " (968)	3'-6 <sup>1</sup> / <sub>8</sub> " (1070)	3'-10 <sup>7</sup> / <sub>8</sub> " (1172)	3'-11 <sup>7</sup> / <sub>8</sub> " (1216)	4'-3 <sup>7</sup> / <sub>8</sub> " (1318)
Unit Dimension		1'-9 <sup>5</sup> / <sub>8</sub> " (549)	2'-1 <sup>5</sup> / <sub>8</sub> " (651)	2'-5 <sup>5</sup> / <sub>8</sub> " (752)	2'-7 <sup>5</sup> / <sub>8</sub> " (803)	2'-9 <sup>5</sup> / <sub>8</sub> " (854)	2'-11 <sup>5</sup> / <sub>8</sub> " (905)	3'-1 <sup>5</sup> / <sub>8</sub> " (956)	3'-5 <sup>5</sup> / <sub>8</sub> " (1057)	3'-9 <sup>5</sup> / <sub>8</sub> " (1159)	3'-11 <sup>5</sup> / <sub>16</sub> " (1202)	4'-3 <sup>5</sup> / <sub>16</sub> " (1303)
Woodwright® Transom Windows (WTR)												
3'-3 <sup>3</sup> / <sub>8</sub> " (1013)	2'-9 <sup>3</sup> / <sub>8</sub> " (860)	2'-5 <sup>3</sup> / <sub>8</sub> " (759)	2'-3 <sup>3</sup> / <sub>8</sub> " (708)	2'-1 <sup>3</sup> / <sub>8</sub> " (657)	1'-9 <sup>3</sup> / <sub>8</sub> " (556)	1'-7 <sup>3</sup> / <sub>8</sub> " (505)	1'-0 <sup>3</sup> / <sub>8</sub> " (317)					
3'-3 <sup>1</sup> / <sub>16</sub> " (999)	2'-9 <sup>1</sup> / <sub>16</sub> " (846)	2'-5 <sup>1</sup> / <sub>16</sub> " (744)	2'-3 <sup>1</sup> / <sub>16</sub> " (694)	2'-1 <sup>1</sup> / <sub>16</sub> " (643)	1'-9 <sup>1</sup> / <sub>16</sub> " (541)	1'-7 <sup>1</sup> / <sub>16</sub> " (490)	1'-0"					
WTR1810	WTR2010	WTR2410	WTR2610	WTR2810	WTR21010	WTR3010	WTR3410	WTR3810	WTR31010	WTR4210		
WTR1815	WTR2015	WTR2415	WTR2615	WTR2815	WTR21015	WTR3015	WTR3415	WTR3815	WTR31015	WTR4215		
WTR1817	WTR2017	WTR2417	WTR2617	WTR2817	WTR21017	WTR3017	WTR3417	WTR3817	WTR31017	WTR4217		
WTR18111	WTR20111	WTR24111	WTR26111	WTR28111	WTR210111	WTR30111	WTR34111	WTR38111	WTR310111	WTR42111		
WTR1821	WTR2021	WTR2421	WTR2621	WTR2821	WTR21021	WTR3021	WTR3421	WTR3821	WTR31021	WTR4221		
WTR1823	WTR2023	WTR2423	WTR2623	WTR2823	WTR21023	WTR3023	WTR3423	WTR3823	WTR31023	WTR4223		
WTR1827	WTR2027	WTR2427	WTR2627	WTR2827	WTR21027	WTR3027	WTR3427	WTR3827	WTR31027	WTR4227		
WTR1831	WTR2031	WTR2431	WTR2631	WTR2831	WTR21031	WTR3031	WTR3431	WTR3831	WTR31031	WTR4231		

Wider sizes continue on page 05

### Notes:

"Unit Dimension" always refers to outside frame to frame dimension.

"Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.

Dimensions in parentheses are in millimeters.

Date: 10/04/16

Scale: 1/8" (3) = 1' (305)

# 400 SERIES

Woodwright® Transom Windows



Rough Opening		Unit Dimension		Woodwright® Transom Window (WTR)		
4'-11 <sup>7</sup> / <sub>8</sub> " (1521)	5'-7 <sup>7</sup> / <sub>8</sub> " (1724)	6'-3 <sup>7</sup> / <sub>8</sub> " (1927)		WTR41010	WTR5610	WTR6210
4'-11 <sup>5</sup> / <sub>16</sub> " (1507)	5'-7 <sup>5</sup> / <sub>16</sub> " (1710)	6'-3 <sup>5</sup> / <sub>16</sub> " (1913)		WTR41015	WTR5615	WTR6215
1'-0 <sup>0</sup> / <sub>8</sub> " (317)	1'-7 <sup>5</sup> / <sub>16</sub> " (490)	1'-0 <sup>0</sup> / <sub>8</sub> " (305)		WTR41017	WTR5617	WTR6217
1'-9 <sup>5</sup> / <sub>16</sub> " (556)	1'-9 <sup>5</sup> / <sub>16</sub> " (541)	1'-9 <sup>5</sup> / <sub>16</sub> " (541)		WTR410111	WTR56111	WTR62111
2'-1 <sup>1</sup> / <sub>8</sub> " (657)	2'-1 <sup>1</sup> / <sub>8</sub> " (643)	2'-1 <sup>1</sup> / <sub>8</sub> " (643)		WTR41021	WTR5621	WTR6221
2'-3 <sup>3</sup> / <sub>8</sub> " (708)	2'-3 <sup>3</sup> / <sub>8</sub> " (694)	2'-3 <sup>3</sup> / <sub>8</sub> " (694)		WTR41023	WTR5623	WTR6223
2'-5 <sup>5</sup> / <sub>8</sub> " (759)	2'-5 <sup>5</sup> / <sub>8</sub> " (744)	2'-5 <sup>5</sup> / <sub>8</sub> " (744)		WTR41027	WTR5627	WTR6227
2'-9 <sup>1</sup> / <sub>8</sub> " (860)	2'-9 <sup>1</sup> / <sub>8</sub> " (846)	2'-9 <sup>1</sup> / <sub>8</sub> " (846)		WTR41031	WTR5631	WTR6231
3'-3 <sup>3</sup> / <sub>8</sub> " (1013)	3'-3 <sup>3</sup> / <sub>8</sub> " (999)	3'-3 <sup>3</sup> / <sub>8</sub> " (999)				

Continuation from page 04

## Notes:

"Unit Dimension" always refers to outside frame to frame dimension.

"Rough Opening" dimensions may need to be increased to allow for use of building wraps, flashing, sill panning, brackets, fasteners or other items.

Dimensions in parentheses are in millimeters.

Date: 10/04/16

Scale: 1/8" (3) = 1' (305)