



## NOTES:

1. REFER TO [SecurEdge 2000 INSTALLATION INSTRUCTION MANUAL](#) FOR THE STEP BY STEP INSTALLATION PROCEDURES AND FOR THE VARIOUS PRODUCT FEATURES AVAILABLE.
2. ENSURE ROOF SLOPES AWAY FROM SecurEDGE.
3. IF INCIDENTAL/TEMPORARY PONDED WATER IS EXPECTED, THE SecurEdge MUST BE ELEVATED AND SCUPPERS PROVIDED FOR DRAINAGE.

 <ul style="list-style-type: none"> <li>—• EPDM</li> <li>—• APPROVED SUBSTRATE</li> <li>—• SEE NOTE(S)</li> </ul>	<p>CARLISLE SecurEDGE 2000</p> <p>For additional information, refer to Specifications</p>	 <p>DETAIL NO. B-1C</p> <p>BALLASTED EPDM</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------