
SecurEDGE 2000

NOTES:

1. REFER TO [SecurEdge 2000 OR 3000 INSTRUCTION MANUALS](#) FOR THE STEP BY STEP INSTALLATION PROCEDURES.
2. IF INCIDENTAL/TEMPORARY PONDED WATER IS EXPECTED, THE SecurEdge MUST BE ELEVATED AND SCUPPERS PROVIDED FOR DRAINAGE.
3. ENSURE ROOF SLOPES AWAY FROM SecurEDGE.



SecurEDGE 3000

<div><div></div><div></div><div>0</div></div> <div><div>● EPDM</div><div>● APPROVED SUBSTRATE</div><div>● SEE NOTE(S)</div></div>	<div>CARLISLE SecurEDGE 2000 & 3000</div> <div>For additional information, refer to Specifications</div>	<div><div>EPDM</div><div>DETAIL NO. U-1E</div><div>THERMOSET UNIVERSAL</div></div>
---	--	--