





NOTES:

1. ROOF DRAIN SIZE AND NUMBER OF DRAINS SHALL BE IN ACCORDANCE WITH THE LOCAL CODES.
2. ALL BOLTS OR CLAMPS MUST BE IN PLACE TO PROVIDE CONSTANT COMPRESSION ON WATER CUT-OFF MASTIC.
3. THE HOLE IN THE MEMBRANE SHALL EXCEED THE DIAMETER OF THE DRAIN PIPE, BUT SHALL BE NO LESS THAN 1/2" (13mm) FROM THE ATTACHMENT POINTS OF THE DRAIN CLAMPING RING.
4. FIELD SPLICES MUST BE LOCATED AT LEAST 6" (152mm) OUTSIDE THE DRAIN SUMP.
5. INSULATION TAPER SHALL NOT BE GREATER THAN 6" (152mm) IN 12" (305mm) HORIZONTAL.



 —• EPDM  —• APPROVED SUBSTRATE  —• SEE NOTE(S)	<p>SURE-SEAL INSERT DRAIN</p> <p>For additional information, refer to Specifications</p>	<div data-bbox="1193 1837 1291 1921"> </div> <div data-bbox="1307 1827 1477 1921"> DETAIL NO. U-6C </div> <div data-bbox="1193 1932 1477 1963"> THERMOSET UNIVERSAL </div>
--	--	---