



# frequently asked questions

---

## XTL FIN

---

### **"How do I wire an XTL Fin to a Microsonic Processor?"**

#### **Forward Transducer**

- 1 - BLACK
- 2 - GREEN
- 3 - SCREEN

#### **Aft Transducer**

- 4 - BLACK
- 5 - RED
- 6 - SCREEN

#### **Power**

- 9 - BLACK (0V)
- 10 - BROWN (+12V)

#### **Sea Temp or Depth Transducer**

- 13 - BLACK
- 14 - WHITE
- 15 - SCREEN

#### **Boat Speed Signal to Main Processor**

- 25 - RED
- 26 - BLUE
- 27 - SCREEN

James Duynisveld

---

B&G Customer Support  
Premier Way  
Abbey Park  
ROMSEY  
SO51 9DH  
UK