

ELECTRODES SOCKETS

THERAPY
II



DIAGNOSE
I



Polymer fuse
150-350mA

EAV+

YELLOW 14 cm



Cu WIRE 0,5 mm²

7 cm

12 cm

14 cm

16 cm



STEP-UP converter instead
of 103 or 503 blue pot

GREEN 14 cm

EAV-



YELLOW 16 cm


YELLOW 16 cm

VEGATEST
SWITCH
(2)

RED 16 cm

RED 16 cm

VEGATEST
SWITCH
(1)




Linear A
(Chinese B)
potentiometer

10k or 50k
depends on
STEP-UP converter

12 cm

12 cm



Insulated crimp fork terminal M4 x 6,4mm

Print without scaling to the page

