


A3D "Mirage" Voron 0.2 Wiring Diagram



Additional Notes:

Please refer to the Siboor Manual for additional information of the base kit

Do not use crossed out USB port (Siboor)

Transitioning to a toolhead board has freed some of the ports below:

- 1.) Uncontrollable hotend fan port
- 2.) Extruder stepper motor port
- 3.) Hotend heater port
- 4.) Part cooling fan port (Now Filter Fan)
- 5.) Hotend thermistor (Now Chamber Thermistor)
- 6.) On / Off 5V LED port

