



LED Tester Build Instructions


- 1) Start with copper side down.
Insert 470 ohm resistor, solder, but do not clip.




- 2) insert and solder 2 pin connector.




- 3) Solder battery clip as shown.




4) Flip and solder resistor to positive lead. Clip.



5) Solder remaining lead to 2 pin connector.



6) Solder 2 pin connector to negative lead.



7) Add strain relief as shown, solder.

