

**emotional** bliss



## CONTENTS

- 01 WELCOME
- 02 JULIA COLE BIOGRAPHY
- 03 SETTING THE SCENE
- 04 ISIS
- 05 CHANDRA
- 06 OPERATING ISIS AND CHANDRA
- 07 FEMBLOSSOM
- 08 JASMINE
- 09 WOMOLIA
- 10 OPERATING FEMBLOSSOM,  
JASMINE AND WOMOLIA
- 11 LED FUNCTIONS
- 12 MESSAGE MODES
- 13 LUBRICANT
- 14 USING YOUR INTIMATE MASSAGER
- 16 THE FOUR PHASES OF FEMALE  
SEXUAL RESPONSE
- 18 USING YOUR INTIMATE MASSAGER  
WITH YOUR PARTNER
- 20 ADAPTER / CLEANING / STORAGE /  
ANTIBACTERIAL AGENTS
- 21 EB QUALITY ASSURANCE

## WELCOME TO EMOTIONAL BLISS

Our goal is to bring you  
bigger, better and more  
emotional orgasms.

Many women who use traditional vibrators say they are dissatisfied with the quality and strength of their orgasms. We have responded to this need with our new generation of intimate massagers by reinventing their function, shape and texture to tease a more powerful climax. Replicating a phallus is no longer recognised as the optimum shape to reach intense orgasms, neither are over-designed, expensive products that often don't work.

Working with sex therapist Julia Cole, Relate and the BASRT (The British Association for Sexual and Relationship Therapy), we set out to conceive a range of intimate massagers that do more than simply look good.

And our customers tell us we have succeeded because we have created products that focus on women's key physical needs such as stimulating the external nerve endings around the clitoris and vaginal lips rather than internally where most people believe arousal originates.

The first step towards a fulfilling sex life is knowledge. For this reason we have provided the Sexologist Section of the website to help people understand how and why our bodies work, both sexually and physically. With more knowledge and a greater understanding of your body you will achieve heightened sexual fulfilment, something we all deserve ...

# JULIA COLE

Julia Cole is a qualified couples counsellor, psychosexual therapist, counselling and therapy supervisor.

Julia says:

'During my work over the past nineteen years I became aware that so many women wanted a vibrator that they could feel comfortable with. They didn't want penile shapes or vibrators that came from the back of a magazine or a sexshop. They wanted a vibrator that stimulated the clitoris and the all-important 'orgasmic platform' (the two inches/50 mm) at the entrance of the vagina. They also asked for a vibrator that actually worked – that gave them the right vibration to achieve orgasm.

As there was nothing on the market that fulfilled this, I have worked with Emotional Bliss to design and manufacture a superb range of intimate massagers that provide the correct stimulation that is needed to achieve multiple orgasms. You can also feel confident that the Emotional Bliss website is friendly and informative without being offensive or intimidating. Emotional Bliss intimate massagers are a brand new way for women to choose and buy their first intimate massager that lives up to its promise – and gives superior sexual satisfaction.



# SETTING THE SCENE

Congratulations on selecting your EB Intimate Massager. You are about to enter a world of increased sexual stimulation and arousal.

Creating a relaxed, sensuous environment to enjoy your EB massager is important, whether you intend to use it alone or with a partner.

Try the following suggestions to create the right mood and get the most out of your intimate massager.

- Start by setting the scene in the room you wish to use. Soft lighting or candles will create a warm and relaxed atmosphere. You may also like to use an aromatherapy oil burner to perfume the room with a seductive scent. Choose musky aromas to arouse your sexual senses.
- Play some music to create the right mood. You could choose a romantic song to put you in the right frame of mind, or a track with a strong bass beat that will match your growing sexual excitement.

- Think about where you are going to use your massager. If you are seated on a chair, sofa or bed, cover it with a slippery satin or a crisp cotton sheet, a soft blanket or a duvet. Different kinds of fabric will give different skin sensations – soft and gentle or sensuous and caressing – that can add to your arousal.
- Once you have arranged the ideal venue, concentrate on yourself. Bathing or showering beforehand can help your skin to feel smooth and sexy, especially if you use a light bath or shower oil.
- Spend time caressing and stroking your body all over before you start. If you want your intimate massager to warm up, switch it on to the maximum setting for a few minutes ahead of use (excluding the Isis or Chandra as they are both fixed speeds).





## ISIS

Isis is one of the smallest rechargeable finger-fitting massagers in the world.

The Isis looks and works like a finger, except the vibrations it creates are a big improvement on nature. It's small and discreet and set at a vibration of 80Hz - the speed proven most likely to stimulate orgasms in women. Use the Isis to tease your clitoris or vaginal lips directly. You Little Wonder!

Slip it on and this little wonder becomes an extension of your finger. It is practically silent and is fully rechargeable so it can run for 2-3 hours - plenty of time to reach that ultimate orgasm (or more than one).

We've included three different-sized finger bands so you can find the right size for you and your partner.

EU Reg Des: 000208863-0002 UK Reg Des: 3016025 US Des Pat No: D523, 151



## CHANDRA

Chandra produces a more intense vibration compared to the Isis.

The Chandra acts like a vibrating finger that you can use to stimulate your clitoris or vaginal lips directly. It's slightly bigger than its little sister Isis but it is still very discrete. With a powerful vibrating speed of 110 Hz the Chandra gives a more intense vibration for women who are looking for that little bit extra. Slip it on and the Chandra becomes an extension of your finger.

We've included three different-sized finger bands, so you can find the right size for you and your partner, and it's fully rechargeable so it can run for 45-60 minutes.

**BOTH PERFECT FOR YOU... AND HIM!**

EU Reg Des: 000208863-0001 UK Reg Des: 3016026 US Des Pat No: S523, 152



# OPERATING ISIS AND CHANDRA

The Isis or Chandra should not be submerged in water.

## TURN ON -OFF

To vibrate press the ① button once


To switch off press the ① button once

## FINGER CLIP

There are 3 finger clips supplied, choose the correct size, and slide the clip as shown in Figure A. Do not twist the finger clip as this will damage the mushroom shaped nipple.

## CHARGING

1. Plug the charger unit into a mains wall socket then connect the small plug into the top of the Isis or Chandra (the clip does not have to be removed).
2. The Isis or Chandra should not be used when connected to the charger. This will reduce the operating life of the motor.
3. The Isis and Chandra will illuminate when connected, this signifies the charging has begun. Place on charge for 12 hours.
4. For the best results always recharge after use.
5. The Isis or Chandra left uncharged for long periods of time may cause damage to the battery.
6. Only use the Emotional Bliss charger supplied.



# FEMBLOSSOM **HEAT**

Offers unique vibrating sensations and requires little movement to operate.

If you're looking for more than just clitoral stimulation, the Femblossom will reach those other sensitive places that deserve arousal too.



The Femblossom's unique, curved design simultaneously caresses the clitoris and the ultra-sensitive lips of the vagina resulting in stronger orgasms. Choose between the different speed settings to find the vibration that suits your mood then use the Femblossom to stroke gently for the optimum sensation.

**As the Temperature Rises ...** While the 'single click' function makes for easier, quieter operation and the variable speed vibration improves arousal, the integral heat function helps to tease and excite your body ...and You're Soon Red-Hot ...

**A TIP!** .....Switch On, select the maximum setting and leave for 10 – 15 minutes before use.

DO NOT cover with a blanket or pillow as this will result in overheating damaging your intimate massager.





## JASMINE HEAT

Creates direct stimulation to individual areas of the clitoris and labia.

The Jasmine provides the ultimate in clitoral stimulation. The textured surface of the tip provides extra arousal around the clitoris and vaginal area to create a range of fantastic sensations and ultimately a powerful orgasm.

Choose between the different speed settings to find the vibration that suits your mood then rotate the Jasmine backwards and forwards for a clitoral orgasm that will have you wondering what you have been missing all these years.

**As the Temperature Rises ...** While the 'single click' function makes for easier, quieter operation and the variable speed vibration improves arousal, the integral heat function helps to tease and excite your body ...and You're Soon Red-Hot ...

**A TIP!** .....Switch On, select the maximum setting and leave for 10 – 15 minutes before use.

DO NOT cover with a blanket or pillow as this will result in overheating damaging your intimate massager.



EU Reg Des: 000208863-0003 UK Reg Des: 3016023 US Des Pat No: D523, 561

## WOMOLIA HEAT

The ultimate massager.

The angled tip of Womolia is perfect for directly stimulating the clitoris but it also reaches the ultra sensitive 'orgasmic platform', the first two inches at the entrance of the vagina. Once you're fully aroused, pushing the tip into your vagina will help you enjoy an intense orgasm.



Choose between the different speed settings to find the level of vibration that suits your mood then lie back and treat yourself to a clitoral orgasm – and find out what you have been missing all these years.

**As the Temperature Rises ...** While the 'single click' function makes for easier, quieter operation and the variable speed vibration improves arousal, the integral heat function helps to tease and excite your body ...and You're Soon Red-Hot ...

**A TIP!** .....Switch On, select the maximum setting and leave for 10 – 15 minutes before use.

DO NOT cover with a blanket or pillow as this will result in overheating damaging your intimate massager.



EU Reg Des: 000208863-0004 UK Reg Des: 3016024 US Des Pat No: D523, 963

# OPERATING FEMBLOSSOM, JASMINE AND WOMOLIA



## MODE ① BUTTON

**To start** your EB intimate massager, gently press once [single click] the ① Mode button and the LED will illuminate.

**To stop**, repeat the same process, [single click].

If your EB intimate massager is started whilst the battery is low then the LED will flash 3 times and will not start. Please place on charge for 12 hours.


## ① ② BUTTONS

There are two buttons ① and ②, these allow you to change the vibrations to suit your mood. ② will select the following programmed setting and ① will decrease the setting. The LED will blink once to indicate a change in vibration. There are 3 individual setting on each of the 3 modes.

# LED FUNCTIONS

For Femblossom, Jasmine and Womolia

LED State	Comments
on	the massager is switched on
off	the massager is switched off
blink twice	① ② selecting the setting
slow flashing	low battery warning
fast flashing	the massager is about to switch off
Charging Mode	
slow phasing	the unit is on a 12 hour charging cycle
constant	fully charged



JASMINE HEAT

FEMBLOSSOM HEAT

WOMOLIA HEAT

# MASSAGE MODES

Note: The intensity of the vibration and heat may vary +/-10% due to the battery or the motor.

**Warning: Prolonged use on higher settings may cause numbness**

## SETTING

## DESCRIPTION

## HEAT

1

Low Pulse Mode



2

Medium Pulse Mode



3

High Pulse Mode



4

Low Constant Mode



5

Medium Constant Mode



6

High Constant Mode



7

Saw Mode



8

Strong Triangle Mode



9

Very Strong Pulse Mode



Maximum Temp: **35°C** / 95°F



Maximum Temp: **42°C** / 108°F



Maximum Temp: **50°C** / 122°F



# LUBRICANT

Emotional Bliss Water Based and Silicon Based lubricants are both extra concentrated making it longer lasting designed to enhance your Emotional Bliss experience:

- Provides long-lasting lubrication
- Non-greasy and odourless
- Tasteless
- Water soluble
- Condom Safe





# USING YOUR INTIMATE MASSAGER

Different things work for different women, so these are only suggestions on how to use your massager



Take time and have fun finding out what works for you, just be patient, relax and enjoy!

- Try wearing silky pants or a thong and run your massager over your vagina and clitoris.
- When you begin to feel aroused, take off your underwear and squeeze a little EB Lubricant on your vaginal lips and clitoris. Use a circling motion over the whole area, but pay particular attention around your clitoris.

- Now try a circling movement around your vaginal lips and up and around your clitoris and back down again to your vaginal lips. As you become more excited, apply a little more pressure and speed to heighten the sensations.
- Slide your massager backwards and forwards over you vaginal lips and clitoris. Then try gently circling the clitoris for more intense stimulation.
- As you become more aroused, place the head of your massager directly on your clitoris and alternate pressing and releasing your hold – play around with the vibration settings to find the perfect vibration.
- Once you feel highly aroused, circle the clitoris repeatedly with your massager. When you feel close to orgasm, press your massager on and around the clitoris.

## FEMBLOSSOM TIP

Find one of the different vibration settings that you feel comfortable with and place the Femblossom so that the curve with the bumpy surface is next to your clitoris. The vibration control buttons will be facing away from your body, so you can easily change speed without having to stop what you're doing.

Slide your massager backwards and forwards over you vaginal lips and clitoris. Then try gently circling the clitoris for a more intense stimulation.

As you reach orgasm, press your massager tightly against the whole vulval area to reach an intense climax.

## WOMOLIA TIP

When you feel ready, try inserting the tip of your massager to a maximum of 50mm. A gentle rocking motion as you push the tip into your vagina will boost the pleasurable sensations.

# THE FOUR PHASES OF FEMALE SEXUAL RESPONSE

## PHASE 01

### Arousal

Touching, caressing and stroking causes the vaginal lips and clitoris to begin to enlarge as the blood flow into them increases. The vagina then begins to extend and widen.

## PHASE 02

### Increased excitement

Further caressing, especially oral sex, cause the clitoris to become fully erect. The vagina begins to produce moisture (lubrication) from specially adapted glands along its walls. The vaginal lips and clitoris then begin to deepen in colour. Internally, the cervix and womb begin to rise inside the woman.

## PHASE 03

### Plateau

Continuing arousal causes this phase of extreme sexual excitement. The clitoris slips back under its hood of skin and the woman may feel the first waves of muscle spasm, which signals the closeness of her orgasm. Her cervix and womb are lifted high inside the abdominal cavity. She will have a greater degree of lubrication. The top of the vagina balloons out, forming a receptive pool for any possible semen to arrive.

## PHASE 04

### Orgasm

The vaginal walls, cervix, the uterus and anal and urethral sphincters contract rhythmically. This is experienced as incredibly pleasurable. Orgasm in women usually lasts between 20 seconds to a minute. Women are capable of multiple orgasms and can be stimulated to orgasm several times in one love making session, although not every woman needs this kind of stimulation.

After orgasm, the womb and cervix return to their usual positions, the clitoris becomes soft again and the blood flow to the vagina and lips returns to its non-aroused state.



# USING YOUR INTIMATE MASSAGER WITH YOUR PARTNER

Let your imagination be your guide.

Emotional Bliss massagers are designed for women, but your partner can join in the action too. Incorporating your massager into your foreplay and lovemaking can be a lot of fun for both of you.

Don't just concentrate on the obvious areas – experiment using your massager on some other highly sensitive erogenous zones, try stroking each other's nipples with the vibrator. Areas like the inside of the elbow, the back of the knee and the nape of the neck are also highly charged with sensitive nerve endings that respond well to the vibrations.

During penetrative sex, if the woman holds her massager against her clitoris while her male partner enters her vagina from the front or behind you will both feel the vibrations.

Most men enjoy the vibration sensation on their testicles. Using a little EB Lubricant, stroke the underneath of the scrotum for added stimulation during oral sex. Or you could try very gently caressing the head of the penis with the massager.

Many men also enjoy having the area around the buttocks and anus stimulated. (Always clean your intimate massager after any kind of anal contact, as infections can easily spread from the anus to the vagina or mouth).

**THE POSSIBILITIES ARE ENDLESS. HAVE FUN EXPLORING!**



# ADAPTOR

## Charging:

Plug the EB Adaptor into a mains wall socket, and then connect the small plug into the back of your EB Intimate Massager. Whilst charging the LED will phase "On and then Off" slowly, after 12 hours the LED will stop phasing "On and Off" and will remain "On" to indicate a full charge.

If left connected to the adaptor for more than 12 hours no damage will be caused, the batteries will simply be kept topped-up. If only part charged, the massager will work for a shorter period of time.

## Technical Specification for the charger:

Input Voltage: 100V-240V AC, 50 / 60Hz  
Output Voltage: 9V DC  
Output Current: 350mA

# CLEANING

Simply use a mild soap to clean your EB Intimate Massager before and after each use. Don't submerge your massager completely in water - just rinse under a tap, avoiding the charger socket. Avoid using cleansing wipes, as this could affect the medical-grade plastic over time and don't clean your massager while it is plugged into the mains or switched on.

# STORAGE

Your Emotional Bliss massager is supplied with a specially designed storage box to accomodate all the individual components.

# ANTIBACTERIAL AGENTS

All Emotional Bliss Massagers have an antibacterial agent incorporated into the manufacturing process of the soft plastic. The antibacterial system incorporates some of the latest technology used in medical research to provide long-term protection.

When in contact with moisture, the outer layer of the chemical matrix in the plastic slowly dissolves, releasing silver ions to the surface. As one layer is hydrolysed releasing silver ions, another layer is exposed, which in turn is hydrolysed and so on. A simple analogy is peeling an onion – as you remove one layer, a new one below is revealed. The silver ions are the biologically active component and are 99.9% or even 99.999% effective against a wide range of micro-organisms.

# EB QUALITY GUARANTEE

## EB QUALITY GUARANTEE

Marital aids and adult toys have been sold around the world for many years, yet there is no recognised safety standard set out for this type of product.

Emotional Bliss hopes to blaze a trail for greater testing and quality in the market. We have invested in high-quality components with high medical standards to produce the first intimate massagers on the global market that achieve full product liability.

We at Emotional Bliss are proud to be pioneers and to set standards globally with our attention to the function, design and materials used in our products.



emotional bliss



## TO ORDER

**[www.emotionalbliss.com](http://www.emotionalbliss.com)**



uk orders **t:** 08700 41 00 22



international orders **t:** +44 8700 41 00 22