


QUICKSTART

VAN PI Dimmy Wired




1 Connection

Connect your Dimmy and your VAN PI Relayboard via an I2C cable.

2 Accessories & power connection

Now connect 9-16V via the supplied plug.



3 Connecting LEDs

Connect your LEDs to the Dimmy.

Don't forget to plug in the fuses!

