


# QUICKSTART

## VAN PI Dimmy Wired




### 1 Connection

Connect your Dimmy and your VAN PI Relayboard via an I2C cable.

### 2 Accessories & power connection

Now connect 9-16V via the supplied plug.

Cable fuses are no longer required in the new version with fuses on the board.



### 3 Connecting LEDs

Connect your LEDs to the Dimmy.

**Don't forget to plug in the fuses!**

