


QUICKSTART

VAN PI Dimmy Standalone

1 Create Image




a) Website:
Start Chrome Browser , connect Wemos ESP32
to your PC >> can be flashed directly from the
browser.
(www.flashesp.pekaway.de)


b) Onboard Flasher:
A flasher is built into the System.
Wemos ESP32 can be flashed with
our integrated Flashtool found in
the Config Menu

2 Assembly

Place the **WEMOS ESP32** on the
board. Insert the board and
cover into the dimmycase
and screw together the cover.



3 Accessories & Power connect



Now connect 9-16V via the
included plug.

Cable fuses are no longer needed in the
new version with fuses on the board.

4 Connect Button and LEDS

Connect the GPIO Pins to
your buttons and add your LEDS.
!do not forget to plug in the fuses!

