


QUICKSTART

VAN PI Dimmy Standalone

1 Create Image




a) Website:
Start Chrome Browser , connect Wemos ESP32 to your PC >> can be flashed directly from the browser.
(flasheesp.pekaway.de)


b) Onboard Flasher in your webinterface:
A flasher is built into the System.
Wemos ESP32 can be flashed with our integrated Flashtool found in the Config Menu

2 Assembly

Place the **WEMOS ESP32** on the board. Insert the board and cover into the dimmycase and screw together the cover.



3 Accessories & Power connect



4 Connect Buttons and LEDS

Connect the GPIO Pins to your buttons and add your LEDS.
Do not forget to plug in the fuses!

