

SECTION INDEX

Section B: Body

Body Construction	B 1
Front and Rear Hoods	
Operations: 1 BO Removing and Installing Front Hood	B 3
2 BO Removing and Installing Hinges for Front Hood	B 4
3 BO Removing and Installing Front Hood Lock	B 6
4 BO Removing and Installing Rear Hood	B 7
5 BO Removing and Installing Hinges for Rear Hood	B 8
6 BO Removing and Installing Rear Hood Lock	B 8
Function of the Hood Latch	B 4
Emergency Access to Front Hood	B 7
Emergency Access to Rear Hood	B 9
Bumpers	
Operations: 7 BO Removing and Installing Front Bumper	B 10
8 BO Removing and Installing Rear Bumper	B 11
Doors and Windows	
Operations: 9 BO Removing and Installing Doors	B 13
10 BO Removing and Installing Door Panels	B 15
11 BO Removing and Installing Door Windows	
Coupe	B 16
Cabriolet/Hardtop	B 17
Roadster	B 18
12 BO Removing and Installing Vent Windows	B 20
13 BO Removing and Installing Door Window Frame	
Coupe	B 20
Cabriolet/Hardtop	B 22
Roadster	B 23
14 BO Removing and Installing Door Lock	B 25
15 BO Removing and Installing Windshield	
Coupe, Cabriolet/Hardtop	B 26
Roadster	B 28
16 BO Removing and Installing Rear Window	B 31
17 BO Removing and Installing Side Window	B 31
Door Weather Strip	B 14
Function of the Door Lock	B 24
Seats	
Operations: 18 BO Removing and Installing Front Seats	B 33
19 BO Removing and Installing Folding Back Rests	B 34
Fittings	
Operations: 20 BO Removing and Installing Door Handles	B 35
21 BO Removing and Installing Mouldings	B 36
22 BO Removing and Installing Grills Hood Ornament, and Porsche Name Plate	B 36
Porsche Name Plate	B 36

Interior

General	B 38
Operations: 23 BO Installing Side Liner	B 38
24 BO Installing Head Liner	B 39
25 BO Installing Front and Rear Fiber Matting	B 41

Pedal Assembly

General	B 44
Operations: 26 BO Removing and Installing Pedal Assembly	B 44

Cabriolet Convertible Top

General	B 46
Operations: 27 BO Raising and Lowering Cloth Top	B 46
28 BO Converting from Soft to Hardtop	B 48
Care of the Cloth Top	B 47

Roadster Top

General	B 52
Operations: 29 BO Removing and Installing Convertible Top	B 52
30 BO Raising and Lowering Convertible Top	B 53

Repairs and Inspection

General	B 56
Measurement	B 56
Chassis Jig	B 57
Operations: 31 BO Measuring Chassis on Jig	B 58
32 BO Tolerances	B 59
33 BO Straightening Front Axle Tubes	B 63
34 BO Attaching New Chassis Members	B 79
35 BO Attaching Interior Panels	B 79
36 BO Attaching Body Panels	B 79
37 BO Front End Repair	B 80
38 BO Rear End Repair	B 81
Drawings: Chassis Dimensions	B 61
Body Work Dimensions for Coupe	B 65
Body Work Dimensions for Interior of Coupe	B 67
Body Work Dimensions for Cabriolet/Hardtop	B 69
Body Work Dimensions for Interior of Cabriolet/Hardtop	B 71
Dimensions for Hardtop	B 73
Body Work Dimensions for Roadster	B 75
Body Work Dimensions for Interior of Roadster	B 77

Paint

General	B 83
Shop Practice	B 83
Spraying Synthetic Enamel	B 84
Lacquer and Enamel Primer	
A — Synthetic Enamel Primer	B 85
B — Lacquer Primer	B 86
Repainting	B 87
Air and Oven Drying Lacquer Paints	B 88