



## Sleeve (4)

P 51



Example of use



Tool


**Use :** To protect the crankcase bores while rotating the crankshaft with the cylinders removed

See operation 36 EN


Subject to change

## Press for installing oil seal

P 73



Example of use



Tool

**Use :** To install crankshaft oil seal in the timing case cover

See operation 38 EN

Subject to change