



Puller for V-belt pulley

P 43



Example of use



Tool


Use: To remove the V-belt pulley from the crankshaft

See operation 42 EN


Subject to change

Socket 36 mm

P 44



Example of use



Tool

Use: To remove and tighten the flywheel gland nut

See operation 41 EN

Subject to change