



## Torque Wrench (50 mkg. 360 ft. lb. cap.)

P 42



Application



Tool


**Use:** To loosen and tighten rear axle nuts, used with P 44, P 44a, and P 36

**See:** Workshop Manual, group R, operation 1 RA


Subject to change

## Socket 36 mm

P 44



Application



Tool

**Use:** To loosen and tighten rear axle nuts, used with P 36, P 42, and P44a

**See:** Workshop Manual, group R, operation 1 RA

Subject to change