


To set an SSID (Service Set Identifier) for Wi-Fi network

1. Open a web browser on a computer or mobile device
2. Log in to the router's admin console



3. Find the Wireless menu

tp-link

Quick Setup

Settings

English

Mode

Logout

Reboot

Status

Wireless

Connect to Network

Extended Network

Network

Advanced Settings

System Tools

TP-Link Cloud

OneMesh

Connect to Host Network

2.4GHz Network:

Connect to 2.4GHz Network

Wireless Scanner

Host 2.4GHz SSID:

Host 2.4GHz Security:

No Security

Host 2.4GHz Password:

5GHz Network:

Connect to 5GHz Network

Wireless Scanner

Host 5GHz SSID:

Host 5GHz Security:

No Security

Host 5GHz Password:

Save

4. Locate the Wireless Network Name (SSID) field
5. Change the default SSID name

tp-link

Quick Setup

Settings

English

Mode

Logout

Reboot

Status

Wireless

Connect to Network

Extended Network

Network

Advanced Settings

System Tools

TP-Link Cloud

OneMesh

Connect to Host Network

2.4GHz Network:

Connect to 2.4GHz Network

Wireless Scanner

Host 2.4GHz SSID:

My Network

Host 2.4GHz Security:

No Security

Host 2.4GHz Password:

5GHz Network:

Connect to 5GHz Network

Wireless Scanner

Host 5GHz SSID:

My Network

Host 5GHz Security:

No Security

Host 5GHz Password:

Save

6. Click Save or Apply to confirm

{If you set password select Security WPA or any other in given list and type password}

7. Reboot the router for the changes to take effect

8. Reconnect all wireless devices using the new SSID