

How to power Off the device?

Just access the SYSTEM MENU (Reboot + TAP on display or TAP down/center) then press STBY

How to power On the device?

Check for battery is not empty, plug the power cord then press button on the rear side once

How to Reboot the device?

Press button on the rear side once

LED1 has hanged, how to recover?

Check for WiFi signal intensity, move nearest to modem or try Sleek Reboot

Server not available

Check for WiFi signal intensity, move nearest to modem or just wait

Trend indicator LED2 has strange behaviour

This indicator needs to have got some statistics to be valid. Typically it will take 2 full cycles to stabilize. Statistics will be erased when configuration parameters have been changed

The display has intermittent brightness

if the battery level is one bar or less, this behavior is normal: please charge the battery.