








When the tank Level is low(below E0) the coil is de_energized. When the water level reaches E3 the coil is energized showing High Level.. E1 is used as a reference.



STEEL FORM – DISHWASHER
Designed by: Robert Mutura Macharia
Reviewed by:

STEEL FORM
Sheet: /AC_ACTUATORS/
File: AC_ACTUATORS.kicad_sch

Title: DISHWASHER

Size: A3	Date: 2022-02-01
KiCad E.D.A. kicad (6.0.0)	

Rev: 1
Id: 2/3

