

BACK

1 24 VDC
2 RS232 TXD
3 RS232 RXD
4 RTS
5 CAN HI
6 CAN LO
7 IN1
8 IN2

9 GND
10 GND
11 RS485A
12 RS485B
13 OUT1
14 OUT2
15 OUT3

Address Switch

J3

J2

1 Not used
2 Auto Start
3 Overload
4 Communication Rate
5 Valve

1 RS-485A*
2 RS-485B*
3 CAN*

*(For Termination)

J9

BOTTOM