




QUICK REFERENCE CARD CVP IMPACK



- A. Emergency Stop
B. Stop (Idle)
C. Start (Production)



1. Barcode Scanner
2. Control Panel
3. Operator Touch Screen
4. Start Button Conveyor



LOADER






PACKER

- | | |
|---------------------------|--------------------------------------|
| 1. CARDBOARD FEEDER(S) * | 5. INVOICE PRINTER / FEEDER (option) |
| 2. ORDER INPUT & SCANNING | 6. TAPER |
| 3. 3D SCANNER | 7. SCALE (option) |
| 4. TEMPLATE CREATION | 8. LABEL PRINTER |


*depending configuration

ORDER INPUT PROCESS

1. Change role (Supervisor/Service)
2. Change language
3. Help menu
4. Change Mode (Normal/ Bundle)
5. Control panel
6. Enter Barcode manually




SIGNALS AND CONTROLS




- Red – Error
Orange – Warning
Green – Production
Blue – Idle

NOTIFICATION




WARNING



ERROR






CONTROL PANEL



- Card board Feed: Upper
Card board feed : Middle
Card board feed : Lower
Show last 3D scan information
Move merge conveyor to front
Clear insert position
Move to replace tape position

SUPPLIES


CARDBOARD



LABELS



TAPE



QUICK REFERENCE CARD CVP IMPACK

HIGH LEAKAGE ELECTRICAL CURRENT



LASER RADIATION



INJURY




MOVING PARTS




- | | |
|----------------------------|-------------------|
| 1. CUT & CREASE | 4. TOP SUPPORT |
| 2. S CURVE | 5. TAPER |
| 3. FOLDER INSERTER PILLARS | 6. WASTE CONVEYOR |

DAILY MAINTENANCE


CUT & CREASE UNIT




S CURVE




FOLDER INSERTER PILLARS



TOP SUPPORT



TAPER ROLLERS





WASTE CONVEYOR





ERROR RECOVERY

OPTIMIZE ORDER INPUT



REMOVING JAMS



IN CASE OF TECHNICAL FAILURE
ASK YOUR LOCAL SERVICE TECHNICIAN.