


SPREAD



BIGTREETECH SKR-mini-E3

SWD

RESET

TFT

PT-DET

SERVO

PROBE

E0-STOP

+12V GND

- HB +

- E0 +

POWER

+FAN0 -

X-STOP

Y-STOP

Z-STOP

TH0

TH1

TH2

POWER