


# G3 Ion



⚠ toe line is not necessarily 15mm distant to pin line - in case of doubts, orient template on pin line


distance aid for placing between old holes  
print on transparent for optimal use  
(turn off using layer function)

⚠ assemble here with other half of template at the mark of your respective boot sole length

ⓘ For midsole position:

- check on your boot, whether the boot center mark is really in the middle (for some boots it isn't)
- align with scale on toe and heel template to mid sole mark on ski (or measure 1/2 sole length from toe/heel edge to mid sole mark)
- when the template is fixed to the ski, check with your bindings and boots inserted, whether positioning is correct (also for screw positions)

⚠ turn off information by using the PDF layer function



⚠ assemble here with other half of template at the mark of your respective boot sole length

⚠ cut out separately and use to find midline



⚠ check scale ⚠

1cm

⚠ DEACTIVATE SCALING WHEN PRINTING ⚠