



Hole dimensions and relative distances are the only thing that matter. OD dimensions whatever works. USB holes are shown without threads or other securing means.

T8 Frontal Vertical Base	
Wootz FVB Block	
May 2020	Rick Kruger