



ILLUSTRATION




*A	for LHD	*B	for RHD
*1	A/F RELAY	*2	EFI MAIN RELAY
*3	ECM	*4	ENGINE ROOM RELAY BLOCK ASSEMBLY
*5	FUSE BLOCK ASSEMBLY - A/F FUSE - EFI FUSE	-	-

ILLUSTRATION

*A






*B



P

*A	for LHD	*B	for RHD
*1	COWL SIDE RELAY BLOCK ASSEMBLY - EFI-NO. 2 FUSE	-	-

ILLUSTRATION



P

*1	AIR FUEL RATIO SENSOR (for Bank 1 Sensor 1)	*2	CHARCOAL CANISTER ASSEMBLY
*3	FUEL TANK CAP ASSEMBLY	*4	HEATED OXYGEN SENSOR (for Bank 1 Sensor 2)
*5	PCV VALVE SUB-ASSEMBLY	*6	PURGE VSV
*7	AIR FUEL RATIO SENSOR (for Bank 2 Sensor 1)	*8	HEATED OXYGEN SENSOR (for Bank 2 Sensor 2)