




## ILLUSTRATION



P

*1	CLUTCH COVER ASSEMBLY	*2	CLUTCH DISC ASSEMBLY
*3	CLUTCH RELEASE FORK SUB-ASSEMBLY	*4	CLUTCH RELEASE FORK SUPPORT BOOT
*5	MANUAL TRANSMISSION ASSEMBLY	*6	RELEASE FORK SUPPORT
*7	RELEASE BEARING HUB CLIP	*8	CLUTCH RELEASE BEARING ASSEMBLY
*9	INPUT SHAFT BEARING	-	-
	N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part

	Multemp 8158 grease or equivalent		Clutch spline grease
---	-----------------------------------	---	----------------------