


VEHICLE IDENTIFICATION NUMBER

NOTICE:
The location of the imprinted vehicle identification number differs depending on the model code, as shown in the illustration.



ENGINE SERIAL NUMBER AND TRANSMISSION SERIAL NUMBER

- a. The engine serial number is stamped on the cylinder block of the engine and the transmission serial number is stamped on the housing as shown in the illustrations.
- i. Engine Serial Number

*A


*B

*C

*A	for 1GR-FE	*B	for 1VD-FTV
*C	for 1HZ	-	-

- ii. Transmission Serial Number

*A



*B



*A

for H150F

*B

for R151F