


*1	REAR STABILIZER BAR	*2	REAR STABILIZER BAR LINK BRACKET
*3	REAR STABILIZER BUSHING	*4	STABILIZER LINK SUB-ASSEMBLY
*5	REAR STABILIZER BRACKET	*6	REAR STABILIZER CUSHION RETAINER
*7	REAR STABILIZER CUSHION	*8	CUSHION
*9	COLLAR	-	-
	N*m (kgf*cm, ft.*lbf): Specified torque	•	Non-reusable part