

Altair® HyperWorks®

2022.2

Save Parts

Parts and part assemblies without a UID cannot be saved to the Library. Considering this, the UID field in the **Save Representation** dialog is user editable.

1. In the Part Browser, right-click on part assemblies or parts and select **Representations** > (and then) **Save** from the context menu.

A checkmark in the Available column indicates that the representation already exists in the repository. A checkmark in the Library column indicates that a revision is already available in the Part Library.

The **Save Representation** dialog opens.

2. Edit the Major Revision and Study Revision columns to reflect the intended revisions.
3. To overwrite representations that already exist in the repository, select the **Overwrite available** checkbox.

Note: Original CAD representations will not be overwritten because the original file location is stored as a link on the part. Enabling **Overwrite available** saves an HyperMesh binary file of the modified CAD representation in the repository.

4. To only save parts locally, disable the **Save to Library** checkbox.

5. Click **OK**.

Unavailable parts are saved, and available parts are overwritten and saved if Overwrite available was selected.




Figure 1.