

Main Page, with Pocket Beagle Connections
Deepwoods Software

Sheet: /
 File: PocketBeagleCommandStation_SMD.sch


Title: Pocket Beagle DCC Command Station (SMD version)

Size: USLetter Date: 2021-04-09

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 1/7



Power Supplies

Deepwoods Software

Sheet: /Power Supplies/

File: PowerSupply.sch

Title: Pocket Beagle DCC Command Station (SMD version)


Size: A4

Date: 2021-04-09

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 2/7



CAN Transceiver

Deepwoods Software

Sheet: /CAN Transceiver/

File: CANTransceiver.sch

Title: Pocket Beagle DCC Command Station (SMD version)


Size: A4

Date: 2021-04-09

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 3/7



Operations DCC Driver

Deepwoods Software

Sheet: /Operations Driver/

File: OpsDriver.sch

Title: Pocket Beagle DCC Command Station (SMD version)



Size: A4

Date: 2021-04-09

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 4/7



Prog and OpenLCB DCC drivers

Deepwoods Software

Sheet: /Prog and LCC Alt H/L Driver/

File: ProgAltDriver.sch

Title: Pocket Beagle DCC Command Station (SMD version)


Size: A4

Date: 2021-04-09



KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Rev: A

Id: 5/7



Railcom Interface		
Deepwoods Software		
Sheet: /Railcomm Interface/		
File: RailCom.sch		
Title: Pocket Beagle DCC Command Station (SMD version)		
Size: A4	Date: 2021-04-09	
KiCad E.D.A.	kiCad 4.0.7+dfsg1-1ubuntu2	Rev: A
		Id: 6/7



Fan Control

Deepwoods Software

Sheet: /Fan Control/

File: FANControl.sch

Title: Pocket Beagle DCC Command Station (SMD version)

Size: A4

Date: 2021-04-09

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 7/7