


Deepwoods Software

Sheet: /Power Supplies/
File: PowerSupply.sch

Title: Pocket Beagle DCC Command Station

Size: A4 Date: 3 mar 2019
KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Rev: A
Id: 2/7



CAN Transceiver

Deepwoods Software

Sheet: /CAN Transceiver/

File: CANTransceiver.sch

Title: Pocket Beagle DCC Command Station


Size: A4

Date: 3 mar 2019

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 3/7



OPS DCC Driver

Deepwoods Software

Sheet: /Operations Driver/

File: OpsDriver.sch

Title: Pocket Beagle DCC Command Station


Size: A4

Date: 3 mar 2019

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 4/7



Programming and Alt drivers

Deepwoods Software

Sheet: /Prog and LCC Alt H/L Driver/

File: ProgAndLCCAltHL.sch

Title: Pocket Beagle DCC Command Station


Size: A4

Date: 3 mar 2019

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 5/7




Railcomm Interface
Deepwoods Software

Sheet: /Railcomm Interface/
 File: Railcomm.sch

Title: Pocket Beagle DCC Command Station

Size: A4
 Date: 3 mar 2019
 KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Rev: A
 Id: 6/7



Fan Control

Deepwoods Software

Sheet: /Fan Control/

File: FanControl.sch

Title: Pocket Beagle DCC Command Station

Size: A4

Date: 3 mar 2019

Rev: A

KiCad E.D.A. kicad 4.0.7+dfsg1-1ubuntu2

Id: 7/7