










Required Components to build TrackerBot




- M3 Nuts **6 pcs.**
- M3 x 6 mm screw **4 pcs.**
- M3 x 8 mm screw **8 pcs.**
- M3 x 30 mm screw **4 pcs.**
- M3 x 25 mm female spacer **8 pcs.**
- M3 x 50 mm female spacer **8 pcs.**


Required Parts









● M3 x 50 mm Female Spacer **4pcs.**



M3 x 8 mm Screw **4pcs.** ●




M3 x 25 mm Female Spacer **4pcs.**




M3 x 8 mm Screw **4pcs.**

MPU 6050 Module



M3 x 12 mm Female Spacer **2pcs.**



REX MainBoard

M3 x 8 mm Screw **2pcs.**



